

Packard Bell dot mr/u and Packard Bell dot mu Service Guide

Service guide files and updates are available
on the ACER/CSD web; for more information,
please refer to <http://csd.acer.com.tw>

PRINTED IN TAIWAN

Revision History

Please refer to the table below for the updates made on this service guide.

Date	Chapter	Updates

Copyright

Copyright © 2009 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Acer is a registered trademark of Acer Corporation.

Intel is a registered trademark of Intel Corporation.

Pentium and Pentium II/III are trademarks of Intel Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Conventions

The following conventions are used in this manual:

SCREEN MESSAGES	Denotes actual messages that appear on screen.
NOTE	Gives bits and pieces of additional information related to the current topic.
WARNING	Alerts you to any damage that might result from doing or not doing specific actions.
CAUTION	Gives precautionary measures to avoid possible hardware or software problems.
IMPORTANT	Reminds you to do specific actions relevant to the accomplishment of procedures.

Preface

Before using this information and the product it supports, please read the following general information.

1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer's "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER-AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

System Specifications 1

- Features 1
- System Block Diagram 4
- Your Notebook Tour 5
 - LCD View 5
 - Top View 5
 - Closed Front View 6
 - Left View 7
 - Right View 7
 - Base View 8
 - Rear View 8
 - Indicators 9
 - TouchPad Basics 10
- Using the Keyboard 11
 - Lock Keys and embedded numeric keypad 11
 - Windows Keys 12
 - Hot Keys 13
 - Special Keys 14
- Hardware Specifications and Configurations 15

System Utilities 25

- BIOS Setup Utility 25
 - Navigating the BIOS Utility 25
 - Information 26
 - Main 27
 - Security 28
 - Boot 31
 - Exit 32
- BIOS Flash Utility 33
 - DOS Flash Utility 34
 - WinFlash Utility 35
- Remove HDD/BIOS Password Utilities 36
 - Removing BIOS Passwords: 37
 - Miscellaneous Utilities 38

Machine Disassembly and Replacement 41

- Disassembly Requirements 41
 - Related Information 41
 - Replacement Requirements 41
 - Pre-disassembly Instructions 42
 - Disassembly Process 43
- External Module Disassembly Process 44
 - External Modules Disassembly Flowchart 44
 - Removing the Battery Pack 45
 - Removing the Dummy Card 46
 - Removing the Hard Disk Drive Module 47
 - Removing the DIMM Module 49
 - Removing the WLAN Module 51
- Main Unit Disassembly Process 53
 - Main Unit Disassembly Flowchart 53
 - Removing the Keyboard 55
 - Removing the Upper Cover 57
 - Removing the Button Board 59
 - Removing the LCD Module 62

Removing the LED Board	64
Removing the Bluetooth Module	66
Removing the I/O Board	67
Removing the Mainboard	69
Removing the CRT Board	71
Removing the Thermal Module	72
Removing the RTC Battery	73
Removing the Speaker Modules	74
LCD Module Disassembly Process	75
LCD Module Disassembly Flowchart	75
Removing the LCD Bezel	76
Removing the Camera Board	77
Removing the LCD Panel	78
Removing the LCD Brackets	80
Removing the FPC Cable	81
Removing the Antennas	82
LCD Reassembly Procedure	84
Replacing the Antennas	84
Replacing the FPC Cable	86
Replacing the LCD Brackets	87
Replacing the LCD Panel	88
Replacing the Camera Board	90
Replacing the LCD Bezel	91
Main Unit Reassembly Process	93
Replacing the Speaker Modules	93
Replacing the RTC Battery	94
Replacing the Thermal Module	95
Replacing the CRT Board	96
Replacing the Main Board	97
Replacing the I/O Card	99
Replacing the Bluetooth Module	101
Replacing the LED Board	102
Replacing the LCD Module	104
Replacing the Button Board	107
Replacing the Upper Cover	110
Replacing the Keyboard	112
Replacing the Wireless LAN Module	113
Replacing the DIMM Module	115
Replacing the Hard Disk Drive	116
Replacing the Battery	118
Replace the Dummy Card	119

Troubleshooting 121

Common Problems	121
Power On Issue	122
No Display Issue	123
Random Loss of BIOS Settings	124
LCD Failure	125
Built-In Keyboard Failure	126
TouchPad Failure	127
Internal Speaker Failure	128
Internal Microphone Failure	129
HDD Not Operating Correctly	130
USB Failure (Right up/down side)	131
Other Failures	131

Intermittent Problems 132
Undetermined Problems 132
POST Code Reference Tables 133

Jumper and Connector Locations 137

Mainboard Top View 137
Mainboard Bottom View 138
Clearing Password Check and BIOS Recovery 139
Mainboard CMOS Discharge 139
BIOS Recovery by Crisis Disk 140

FRU (Field Replaceable Unit) List 141

Packard Bell dot Exploded Diagrams 141
Main Assembly 142
LCD Assembly 144
Screw List 150

Model Definition and Configuration 151

Test Compatible Components 153

Online Support Information 157

Index 159

System Specifications

Features

Below is a brief summary of the computer's many features:

Operating System

- Genuine Windows Vista ®

Platform

- Intel Centrino® processor technology, featuring:
 - Intel® Core™2 Solo processor SU3500 (3 MB L2cache, 1.40 GHz, 800 MHz FSB, 5.5 W), supporting Intel® 64 architecture
 - Mobile Intel® GS45 Express Chipset
 - Intel® Wireless WiFi Link 5100 (dual-band quad-mode 802.11a/b/g/Draft-N) Wi-Fi CERTIFIED™ network connection, featuring MIMO technology
 - Intel® Wireless WiFi Link 5100 (dual-band 802.11a/b/g) Wi-Fi CERTIFIED™ network connection, featuring MIMO technology (available only in Russia, Pakistan, Ukraine)
- Intel® Celeron® mobile processor 723 (1 MB L2 cache, 1.20GHz, 800 MHz FSB, 10 W), supporting Intel® 64 architecture
- Mobile Intel® GS45 Express Chipset
- 802.11b/g/Draft-N Wi-Fi CERTIFIED™ network connection2

System Memory

- Dual-channel DDR2 SDRAM support:
- Up to 2 GB of DDR2 667 MHz memory,
- upgradeable to 4 GB using two soDIMM modules (for 32-bit OS)

Display and graphics

- 11.6" HD 1366 x 768 (WXGA) pixel resolution, high-brightness (200-nit) Packard Bell Diamond View TFT LCD 16:9 aspect ratio
- Mobile Intel® GS45 Express Chipset with integrated 3D graphics, featuring Intel® Graphics Media Accelerator 4500MHD (Intel® GMA 4500MHD) with up to 1759 MB of Intel® Dynamic Video Memory Technology 5.0 (64 MB of dedicated video memory, up to 1695 MB of shared system memory), supporting Microsoft® DirectX® 10

Storage subsystem

- 2.5" 9.5mm 160 GB or larger hard disk drive
- Multi-in-1 card reader

Audio subsystem

- High-definition audio support
- Two built-in stereo speakers
- MS-Sound compatible
- Built-in digital microphone
- S/PDIF (Sony/Philips Digital Interface) support for digital speakers

Communication

- Integrated Acer Crystal Eye webcam, supporting 0.3-megapixel resolution
- WLAN: Acer InViLink™ 802.11b/g Wi-Fi CERTIFIED® network connection, supporting Acer SignalUp™ wireless technology
- LAN: 10/100 Mbps Fast Ethernet
- WPAN: Bluetooth® 2.0 or 2.1+EDR
- WWAN: UMTS/HSPA at 850/1900/2100MHz and quad-band GSM/GPRS/EDGE(850/900/1800/1900 MHz)(for 3G models)

Privacy control

- Kensington lock slot
- BIOS user, supervisor, HDD passwords

Dimensions and Weight)

- 285 (W) x 204 (D) x 22.1/30 (H) mm (11.22 x 8.03 x 0.87/1.18 inches)
- 1.35 kg (2.97 lbs.) with 6-cell battery pack

Power subsystem

- 47.52 W 4400 mAh 6-cell Li-ion battery pack (for Intel® Celeron® 723 only):
 - 6-hour battery life⁹
- 62.16 W 5600 mAh 6-cell Li-ion battery pack (for Intel® Core™2 Solo SU3500 only):
 - 8-hour battery life⁹
- Energy Star® 5.0
- 30W adaptor with power cord

Input devices

- 84-/85-/88-key full-size keyboard, with inverted "T" cursor layout
- Touchpad pointing device with two buttons

I/O interface

- Multi-in-1 card reader
- Three USB 2.0 ports
- HDMI™ port with HDCP support
- External display (VGA) port
- Headphone/speaker/line-out jack with S/PDIF support


-
- Microphone-in jack
 - Ethernet (RJ-45) port
 - DC-in jack for AC adapter

Environment

- Temperature:
 - Operating: 5°C to 35°C
 - Non-operating: -20°C to 65°C
- Humidity (non-condensing):
 - Operating: 20% to 80%
 - Non-operating: 20% to 80%

NOTE: The specifications listed above are for reference only. The exact configuration of the PC depends on the model purchased.

System Block Diagram



Your Notebook Tour

This section provides an overview of the features and functions of the notebook.

LCD View



Icon	Item	Description
	Webcam	Web camera for video communication.
	Microphone	Internal microphone for sound recording.

Top View



Icon	Item	Description
	HDD	Indicates when the HDD is active.
	Num Lock	Lights up when the Num Lock is activated.
	Caps Lock	Lights up when the Caps Lock is activated.
	Keyboard	For entering data into your computer


Icon	Item	Description
	Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
	Power	Indicates the computer's power status.
	Battery	Indicates the computer's battery status. 1. Charging: The light shows amber when the light is charging. 2. Fully charged: the light shows blue when in AC mode.
	Bluetooth	Indicates the status of Bluetooth communication (only for certain models)
	Communication indicator	Indicates the status of WLAN/3G communication.
	Click buttons (left, and right)	The left and right buttons function like the left and right mouse buttons.
	Palmrest	Comfortable support area for your hand when using the computer.
	Power button/indicator	Turns the computer on and off.

Closed Front View




Icon	Item	Description
	Bluetooth communication switch	Enables/disables the Bluetooth function.
	3G/Wireless LAN communication switch	Enables/disables the 3G/Wireless LAN function.
	Speakers	Left and right speakers deliver stereo audio output.

Left View




Icon	Item	Description
	External display (VGA) port	Connects to a display device (e.g. external, LCD monitor, LCD projector).
	DC-in jack	Connects to an AC adapter.
	Ventilation slots	Enable the computer to stay cool, even after prolonged use.
HDMI	HDMI port	Supports high definition digital video connections.
	USB 2.0 port	Connects to USB 2.0 devices (e.g., USB mouse, USB camera).

Right View




Icon	Item	Description
	Multi-in-one card reader	Accepts Secure Digital (SD), MultiMediaCard(MMC), Memory Stick(MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD). Note: Push to remove/install the card. ONLY one card can operate at any given time.
	Headphones/ speaker/line-out jack with S/PDIF support.	Connects to audio line-out devices (e.g., speakers, headphones).
	Microphone-in jack	Accepts inputs from external microphones.
	USB 2.0 port	Connects to USB 2.0 devices (e.g. USB mouse).
	Kensington lock slot	Connects to a Kensington-compatible computer security lock.
	Ethernet RJ-45) port	Connects to an Ethernet 10/100/1000-based network.

Base View



Icon	Item	Description
	Battery bay	Houses the computer's battery pack. Note: The battery shown is for reference only. Your PC may have a different battery depending on the model purchased.
	Battery lock	Locks the battery in position
	Hard disk bay	Houses the computer's hard disk (secured with screws)
	Memory compartment	Houses the computer's main memory.
	Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the opening the fan.
	Battery release latch	Releases the battery for removal.

Rear View



Icon	Item	Description
	Battery bay	Houses the computer's battery pack. Note: The battery shown is for reference only. Your PC may have a different battery depending on the model purchased.

Indicators


The computer has several easy-to-read status indicators. The battery indicator is visible even when the computer cover is closed.

Icon	Function	Description
	Power	Indicates the computer is on or off.
	Battery	Indicates the computer's battery status.
	Bluetooth	Indicates the status of Bluetooth communication.
	Wireless LAN	Indicates the status of Wireless LAN communication.
	HDD	Indicates when the hard disk drive is active.
	Num Lock	Lights up when Num Lock is activated.
	Caps Lock	Lights up when Caps Lock is activated.

NOTE: 1. **Charging:** The battery light shows amber when the battery is charging. 2. **Fully charged:** The light shows green when in AC mode.

TouchPad Basics

The following items show you how to use the TouchPad:



- Move your finger across the TouchPad (1) to move the cursor.
- Press the left (2) and right (3) buttons located beneath the TouchPad to perform selection and execution functions. These two buttons are similar to the left and right buttons on a mouse. Tapping on the TouchPad is the same as clicking the left button.

Function	Left Button (2)	Right Button (3)	Main TouchPad (1)
Execute	Quickly click twice.		Tap twice (at the same speed as double-clicking a mouse button).
Select	Click once.		Tap once.
Drag	Click and hold, then use finger on the TouchPad to drag the cursor.		Tap twice (at the same speed as double-clicking a mouse button); rest your finger on the TouchPad on the second tap and drag the cursor.
Access context menu		Click once.	

NOTE: When using the TouchPad, keep it - and your fingers - dry and clean. The TouchPad is sensitive to finger movement; hence, the lighter the touch, the better the response. Tapping too hard will not increase the TouchPad's responsiveness.

Using the Keyboard

Your computer has a close-to-full-sized keyboard and an embedded numeric keypad, separate cursor, lock, function and special keys.

Lock Keys and embedded numeric keypad

The keyboard has three lock keys which you can toggle on and off.

Lock key	Description
Caps Lock	When Caps Lock is on, all alphabetic characters typed are in uppercase.
Num Lock <Fn> + <F11>	When Num Lock is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators +, -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad.
Scroll Lock <Fn> + <F12>	When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.

Desired access	Num Lock on	Num Lock off
Number keys on embedded keypad	Type numbers in a normal manner.	
Cursor-control keys on embedded keypad	Hold <Shift> while using cursor-control keys.	Hold <Fn> while using cursor-control keys.
Main keyboard keys	Hold <Fn> while typing letters on embedded keypad.	Type the letters in a normal manner.

Windows Keys

The keyboard has two keys that perform Windows-specific functions.

Key	Description
 Windows key	Pressed alone, this key has the same effect as clicking on the Windows Start button; it launches the Start menu. It can also be used with other keys to provide a variety of functions: <>: Open or close the Start menu <> + <D>: Display the desktop <> + <E>: Open Windows Explore <> + <F>: Search for a file or folder <> + <L>: Lock your computer (if you are connected to a network domain), or switch users (if you're not connected to a network domain) <> + <M>: Minimizes all windows <> + <R>: Open the Run dialog box <> + <U>: Open Ease of Access Center <> + <BREAK>: Display the System Properties dialog box <> + <TAB>: Cycle through programs on the taskbar <CTRL> + <> + <F>: Search for computers (if you are on a network) Note: Depending on your edition of Windows XP, some shortcuts may not function as described.
 Application key	This key has the same effect as clicking the right mouse button; it opens the application's context menu.

Hot Keys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness and volume output.

To activate hotkeys, press and hold the **<Fn>** key before pressing the other key in the hotkey combination.

Hotkey	Icon	Function	Description
<Fn> + <F2>		System Properties	Display the System Properties dialog box.
<Fn> + <F3>		Bluetooth communication switch	Enables/disables the Bluetooth function.
<Fn> + <F4>		Sleep	Puts the computer in Sleep mode.
<Fn> + <F5>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<Fn> + <F6>		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
<Fn> + <F8>		Speaker toggle	Turns the speakers on and off.
<Fn> + <▷>		Brightness up	Increases the screen brightness.
<Fn> + <◁>		Brightness down	Decreases the screen brightness.
<Fn> + <△>		Volume up	Increases the sound volume.
<Fn> + <▽>		Volume down	Decreases the sound volume.

Special Keys

You can locate the Euro symbol and the US dollar sign at the upper-center and/or bottom-right of your keyboard.

The Euro symbol

1. Open a text editor or word processor.
2. Hold <Alt Gr> and then press the <5> key at the upper-center of the keyboard.

NOTE: Some fonts and software do not support the Euro symbol. See www.microsoft.com/typography/faq/faq12.htm for more information.

The US dollar sign

1. Open a text editor or word processor.
2. Hold <Shift> and then press the <4> key at the upper-center of the keyboard.

NOTE: This function varies according to the language settings.

Hardware Specifications and Configurations

Processor

Item	Specification
CPU type	Intel Penryn SFF (ULV)
CPU package	Micro-FCBGA 956 balls
Chipset	Intel Crestline GS45 SFF and ICH9M SFF
Features	- Supports Intel architecture with Dynamic execution. - On-die, primary 32-kB instruction cache and 32-kB write-back data cache. - On-die, up to 3MB second level shared cache with advanced transfer cache architecture. - Streaming SIMD Extensions 2 (SSE2), Streaming SIMD Extensions 3 (SSE3) - Supplemental streaming SIMD extensions 3 (SSSE3) and SSE4.1 instruction sets. 800MHz source-synchronous front side bus (FSB) - Advanced power management features including Enhanced Intel SpeedStep® Technology and dynamic FSB frequency switching. - Digital thermal sensor (DTS). - Execute disable bit support for enhanced security. - Intel® Dynamic Acceleration Technology and Enhanced Multi Threaded Thermal Management (EmTTM). - Support enhanced Intel Virtualization Technology.

Processor Specifications

Item	CPU Speed	Cores	Mfg Tech	FSB Speed	Cache Size	Package	Power	Acer P/N
Core2Solo SU3500	1.4G	1	45nm	800 MHz	3M	BGA	5.5W	KC.35B0 1.SSU
Celeron 723	1.2G	TBC	45nm	800 MHz	1M	BGA	10W	KC.NB00 1.723
Core2Duo SU4100	TBC	2	45nm	800 MHz	2M	BGA	TBC	KC.41B0 1.DSU

CPU Fan True Value Table

CPU Temperature (Celcius)	Fan Speed (RPM)	SPL Spec (dBA)
38	2400	23
43	3300	26
50	4000	29
56	4500	31

Throttling 50%: On= 90°C; OFF=80°C

OS shut down at 95°C; H/W shut down at 85°C

North Bridge Specifications

Item	Specification
Chipset	Intel Crestline GS45 SFF
Package	FCBGA 1363 balls
Features	• Processor hosts bus supports 667/800/1066MHz FSB support. • Supports Dual Channel DDR2 SDRAM at 667/800MHz • Integrated SDRAM controller up to 8GB (2 SODIMM support) • DMI x2 and DMI x4 for connection between GMCH and ICH9M

South Bridge Specifications

Item	Specification
Chipset	ICH9M SFF
Package	BGA 676 balls
Features	• Upstream accelerated Hub architecture interface for access to GMCH. • PCI Express Base Specification, Revision 1.1 support. • PCI 2.3 interface. (4 PCI Request/Grant pairs). • ACPI Power Management Logi Support. • Enhanced DMA controller, interrupt controller, timers functions. • Integrated Serial ATA host controllers with independent DMA operation on six ports and AHCI support. • USB 1.1 and USB 2.0 Host controllers. • Supports Intel High Definition Audio (Intel HD Audio) Interface. • Supports Intel® Matrix Storage Technology. • Supports Intel® Active Management Technology. • Low Pin Count (LPC) interface. • 6 PCIe ports.

System Memory

Item	Specification
Memory size	0MB (No on-board Memory)
DIMM socket number	2 sockets
Supports memory size per socket	2GB
Supports maximum memory size	4GB for 64bit OS (with two 2GB SO-DIMM)
Supports DIMM type	DDR2 Synchronous DRAM
Supports DIMM Speed	800/667 MHz

Video Specifications

Item	Specification
Chipset	Intel® GS45 Express Chipset
Package	• 1329-ball FCBGA • Size: 34mm x 34mm • Ball pitch: 0.7mm

Item	Specification
Features	• Microsoft Windows Vista* Premium support with the highest level of Windows Aero* experience • Blu-ray* logo capable HD video playback, with native support for Blu-ray* drives • Great 3D graphics performance • Intel® Clear Video Technology for excellent video quality

Hard Disk Drive Interface

Item	Specifications					
Vendor & Model Name	Hitachi HTS545050B 9A300	Hitachi HTS545032B 9A300	Hitachi HTS545025B 9A300	Hitachi HTS545016B 9A300	Hitachi HTS543225L 9A300	Hitachi HTS543216L9 SA00
Capacity (GB)	500	320	250	160	250	160
Bytes per sector	512					
Data heads	4	3	2	2	3	2
Drive Format						
Disks	2	2	1	1	2	1
Spindle speed (RPM)	5400					
Performance Specifications						
Buffer size	8MB					
Interface	SATA					
Internal transfer rate (Gbits/sec, max)	3GB/s maximum					1.5GB/s maximum
I/O data transfer rate (Mbytes/sec max)	875 Mbits/s maximum			845 Mbits/s maximum	775Mbits/s maximum	729Mbits/s maximum
DC Power Requirements						
Voltage	+5.0V ± 5%.					

Item	Specifications			
Vendor & Model Name	Seagate ST9160310AS	Seagate ST9250315AS	Seagate ST9320320AS	Seagate ST9500325AS
Capacity (GB)	160	250	320	500
Bytes per sector	512	512	512	512
Data heads	2	2	4	4
Drive Format				
Disks	1	1	2	2
Spindle speed (RPM)	5400	5400	5400	5400

Item	Specifications			
Performance Specifications				
Buffer size	8 MB	8 MB	8MB	8 MB
Interface	SATA	SATA	SATA	SATA
Internal transfer rate (Mbits/sec, max)	830	1175	830	1175
I/O data transfer rate (Mbytes/sec max)	875 Mbits/s maximum			845 Mbits/s maximum
DC Power Requirements				
Voltage	+5.0V ± 5%.			

Item	Specifications			
Vendor & Model Name	Toshiba MK1655GSX	Toshiba MK2555GSX	Toshiba MK3255GSX	Toshiba MK5055GSX
Capacity (GB)	160	250	320	500
Bytes per sector	512	512	512	512
Data heads	2	2	4	4
Drive Format				
Disks	1	1	2	2
Spindle speed (RPM)	5400			
Performance Specifications				
Buffer size	8MB			
Interface	SATA			
Internal transfer rate (Mbits/sec, max)	363 ~ 952 typical			
I/O data transfer rate (Mbytes/sec max)	300			
DC Power Requirements				
Voltage	5V ±5%			

Item	Specifications			
Vendor & Model Name	Western Digital WD1600BEVT-22ZCT0	Western Digital WD2500BEVT-22ZCT0	Western Digital WD3200BEVT-22ZCT0	Western Digital WD5000BEVT-22ZAT0
Capacity (GB)	160	250	320	500
Bytes per sector	512			
Data heads	2	4	3	4
Drive Format				
Disks	1	2	2	2

Item	Specifications
Spindle speed (RPM)	5400
Performance Specifications	
Buffer size	8 MB
Interface	SATA
Internal transfer rate (Mbits/sec, max)	N/A
I/O data transfer rate (Mbytes/sec max)	300
DC Power Requirements	
Voltage	5V ±5%

BIOS

Item	Specification
BIOS vendor	Insyde
BIOS Version	3.5
BIOS Features	- Flash ROM 1MB - Support ISIPP - Support Acer UI - Support multi-boot - Suspend to RAM (S3) / Disk (S4) - Various hot-keys for system control - Support SMBUS 2.0, PCI2.3 - ACPI 2.0 compliance with Intel Speed Step Support C1e, C2, C3 and S3, S4,S5 for mobile CPU. - DMI utility for BIOS serial number configuration/asset tag - Support PXE - Support Y2K solution - Support Win Flash Wake on LAN from S3 - Wake on LAN form S4 in AC mode - System information

LCD 11.6"

Item	Specifications			
Vendor/model name	AUO B11.6XW02	CMO N116B6-L02	LG LP116WH1-TLA1	Samsung LTN116AT01-A01
Screen Diagonal (mm)	11.6"	11.6"	11.6"	11.6"
Display Area (mm)	256.125 x 144 (11.6" diagonal)			
Display resolution (pixels)	1366 x 768	1366 x 768	1366 x 768	1366 x 768
Pixel Pitch (mm)	0.1875 x 0.1875	0.1875 x 0.1875	0.1875 x 0.1875	0.2265(H) x 0.2265(V)
Typical White Luminance (cd/m ²) also called Brightness	200	200	200	200
Contrast Ratio	500:1	500:1	500:1	500:1
Response Time (Optical Rise Time/Fall Time) msec	8	7	8	8

Item	Specifications			
Typical Power Consumption (watt)	4.0	4	4	2.85
Weight (without inverter)	255g	225g	255g	255g
Physical Size (mm)	268 (L) x 161.5 (W)	268 x 161.5 x 5	268.0 x 161.5	268.0 x 161.5
Electrical Interface	LVDS	LVDS	LVDS	LVDS
Viewing Angle (degree) Horizontal (Right) / (Left) Vertical (Upper) / (Lower)	45/45 20/40	45/45 20/45	45/45 20/40	TBD

Bluetooth

Item	Specification
Bluetooth Controller	Bluetooth module Foxconn Bluetooth BRM 2046 BT2.1 (T60H928.33) F/W:861
Features	- Fully Qualified Bluetooth v2.1 with Class 2 specification RF output power. - Enhanced Data Rate (EDR) compliant. - Full Piconet and Scatternet operation. - Integrated PIFA Antenna with better RF performance. - USB 2.0 compliant interface. - F/W upgradable via Flash downloads. - Very low power consumption. - Support Coexistence with Intel WCS (Wireless Coexistence System) & AFH (Adaptive Frequency Hopping).

Audio Codec and Amplifier

Item	Specification
Audio Controller	Realtek ALC269X
Features	- Headphone-out with S/PDIF, Line-In and Microphone-In. 2 stereo ADCs support 16/20/24-bit PCM format recording simultaneously.

LAN Interface

Item	Specification
LAN Chipset	ATHEROS AR8131L
Package	48pin QFN

Item	Specification
Features	- The AR8131L is the third generation Gigabit Ethernet (GbE) controller solution from Atheros. It is an ultra-high performance, ultralow cost, and ultra-low power fully integrated 10/100/1000 Mbps NIC/LOM Ethernet controller perfectly suited for both PC and embedded applications. - The AR8131L combines a 10/100/1000BASE-T GbE media access controller (MAC), a triplespeed Ethernet physical layer transceiver (PHY), and a PCI Express bus interface. - The AR8131L is compliant with IEEE 802.3u specification for 10/100 Mbps Ethernet and IEEE 802.3ab specification for 1000 Mbps Ethernet. - The AR8131L device combines pulse shaping, Tx/Rx PCS, echo canceller, NEXT canceller, equalizer, decoder, and timing recovery functions to deliver robust signal performance in noisy environments. - The AR8131L GbE controller supports checksum offload features for IP, TCP, and UDP,

Keyboard

Item	Specification
Type	ACER NT1T JM11 Black
Total number of keypads	86/87/91
Windows logo key	Yes
Internal & external keyboard work simultaneously	Yes
Features	Supports application keys for Windows XP version

Media Card Reader

Item	Specification
Chipset	Alcor AU6433
Features	- Fully compatible with USB2.0 High Speed and backward compatible with USB1.1 specifications - Supports multiple flash card interfaces, including SD/MMC/xD/MS. - Supports single LUN 48-pin LQFP

Camera

Item	Specifications		
Vendor and model	Lite On Model No. 09P2SF001	Suyin Model No.CN0316-S30C-OV06-1	Chicony CNF9011
Type	640 x 480 VGA (0.3M) size 1/6" CMOS	640 x 480 VGA (0.3M) size 1/6" CMOS	640 x 480 VGA (0.3M) size 1/6" CMOS
Interface	USB 2.0 high speed interface	USB 2.0 high speed interface	USB 2.0 high speed interface
Optical aperture	F2.4	F2.4	F2.4 ± 5%
Focusing range	18.65~Infinite, focus on 48cm	40 cm to Infinity	17.4cm ~ Infinity, focus on 40cm

Item	Specifications		
Dimensions (L x W x H mm)	65 x 8 x 3.84 +/- 0.25 (H) mm	65X 7.9X 3.8+/-0.2mm	64.8±0.3 X 7.9±0.1 X 3.64+0.15/-0.25 mm
Sensor type	CMOS (OV9710)	CMOS image sensor	CMOS
Pixel resolution	640x480	640X480	640 x 480
Pixel size	TBD	3.6um X3.6um	TBD
Image size	TBD	2.36mm(H) X1.76mm(V)	TBD

Wireless LAN

Item	Specification	Specification	Specification	Specification
Type	Atheros HB93 1x2 BGN	Intel MM#903341	Intel MM#897072	Intel MM#895373
802.11g				
Radio Technology	IEEE 802.11g standard compliant			
Operating Frequency	2412 ~ 2484MHz ISM band			
Modulation Schemes	OFDM, DQPSK, DBPSK and CCK			
Channel Numbers	1---11 channels for active channels 12---13 channels for passive channels			
Data Rate	54Mbps with fall back rates of 48, 36, 24, 18, 12, 9 and 6Mbps			
Media Access Protocol	CSMA/CA with ACK			
Transmitter Output Power	Typical 13.5 dBm for 54Mbps			
802.11b				
Radio Technology	IEEE 802.11b Direct Sequence Spread Spectrum			
Operating Frequency	2412 ~ 2484MHz ISM band			
Modulation Schemes	DQPSK, DBPSK and CCK			
Channel Number	1---11 channels for active channels 12---13 channels for passive channels			
Data Rate	11Mbps with fall back rates of 5.5, 2, and 1Mbps			
Media Access Protocol	CSMA/CA with ACK			
Transmitter Output Power	18dBm typically			

Battery

Item	Specification
	6 Cell
Vendor & model name	SANYO UM-2009E Li-Ion 3S2P PANASONIC UM-2009E Li-Ion 3S2P SIMPLO UM-2009E Li-Ion 3S2P SIMPLO UM-2009E Li-Ion 3S2P
Battery Type	Li-ion

Item	Specification
	6 Cell
Pack capacity	SANYO 6 cell 4400mAh SANYO 6 cell 5600mAh PANASONIC 6 cell 4400mAh PANASONIC 6 cell 5800mAh SAMSUNG 6 cell 4400mAh SAMSUNG 6 cell 5600mAh LGC 6 cell 5600mAh
Number of battery cell	6
Package configuration	3 cells in series, 2 series in parallel

System Utilities

BIOS Setup Utility

The BIOS Setup Utility is a hardware configuration program built into your computer's BIOS (Basic Input/Output System).

Your computer is already properly configured and optimized, and you do not need to run this utility. However, if you encounter configuration problems, you may need to run Setup. Please also refer to Chapter 4 Troubleshooting when problem arises.

To activate the BIOS Utility, press **F2** during POST (when **Press <F2> to enter Setup** message is prompted on the bottom of screen).

Press **F2** to enter setup. The default parameter of F12 Boot Menu is set to "disabled". If you want to change boot device without entering BIOS Setup Utility, please set the parameter to "enabled".

Press **<F12>** during POST to enter multi-boot menu. In this menu, user can change boot device without entering BIOS SETUP Utility.

Navigating the BIOS Utility

There are six menu options: Information, Main, Advanced, Security, Power, Boot, and Exit.


Follow these instructions:

- To choose a menu, use the left and right arrow keys.
- To choose an item, use the up and down arrow keys.
- To change the value of a parameter, press **F5** or **F6**.
- A plus sign (+) indicates the item has sub-items. Press **Enter** to expand this item.
- Press **Esc** while you are in any of the menu options to go to the Exit menu.
- In any menu, you can load default settings by pressing **F9**. You can also press **F10** to save any changes made and exit the BIOS Setup Utility.

NOTE: You can change the value of a parameter if it is enclosed in square brackets. Navigation keys for a particular menu are shown on the bottom of the screen. Help for parameters are found in the Item Specific Help part of the screen. Read this carefully when making changes to parameter values. **Please note that system information is subject to different models.**

Information

The Information screen displays a summary of your computer hardware information.



NOTE: The system information is subject to different models.

Parameter	Description
CPU Type	This field shows the CPU type and speed of the system.
CPU Speed	This field shows the speed of the CPU.
HDD Model Name	This field shows the model name of HDD installed on primary IDE master.
HDD Serial Number	This field displays the serial number of HDD installed on primary IDE master.
ATAPI Model Name	This field displays the model name of the installed ODD drive.
System BIOS Version	Displays system BIOS version.
VGA BIOS Version	This field displays the VGA firmware version of the system.
Serial Number	This field displays the serial number of this unit.
Asset Tag Number	This field displays the asset tag number of the system.
Product Name	This field shows product name of the system.
Manufacturer Name	This field displays the manufacturer of this system.
UUID Number	Universally Unique Identifier (UUID) is an identifier standard used in software construction, standardized by the Open Software Foundation (OSF) as part of the Distributed Computing Environment (DCE).

Main

The Main screen allows the user to set the system time and date as well as enable and disable boot option and recovery.

InsydeH20 Setup Utility		Rev. 3.5
Information	Main	Security Boot Exit
System Time: [19:10:59] System Date: [06/09/2009] System Memory: 640 K Total Memory: 4096 MB Video Memory: [64MB] Quiet Boot [Enabled] Network Boot [Enabled] F12 Boot Menu [Disabled] D2D Recovery [Enabled] SATA Mode [AHCI Mode]		Item Specific Help This is the help for the hour field. Valid range is from 0 to 23. INCREASE/REDUCE: F5/F6
F1 Help ↑↓ Select Item F5/F6 Change Values F9 Setup Default ESC Exit ← Select Menu Enter Select ► SubMenu F10 Save and Exit		


NOTE: The screen above is for your reference only. Actual values may differ.

The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Format/Option
System Time	Sets the system time. The hours are displayed with 24-hour format.	Format: HH:MM:SS (hour:minute:second)
System Date	Sets the system date.	Format MM/DD/YYYY (month/day/year)
System Memory	This field reports system memory size.	N/A
Total Memory	This field reports the memory size of the system. Memory size is fixed to 4096MB.	N/A
Video Memory	Shows the video memory size. VGA Memory size=32 MB	N/A
Quiet Boot	This will hide POST messages while booting.	Option: Enabled or Disabled
Network Boot	Enables, disables the system boot from LAN (remote server).	Option: Enabled or Disabled
F12 Boot Menu	Enables, disables Boot Menu during POST.	Option: Enabled or Enabled
D2D Recovery	Enables, disables D2D Recovery function. The function allows the user to create a hidden partition on hard disc drive to store operation system and restore the system to factory defaults.	Option: Enabled or Disabled
SATA Mode	Control the mode in which the SATA controller should operate.	Option: AHCI or IDE

Security

The Security screen contains parameters that help safeguard and protect your computer from unauthorized use.



The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.


Parameter	Description	Option
Supervisor Password Is	Shows the setting of the Supervisor password	Clear or Set
User Password Is	Shows the setting of the user password.	Clear or Set
Set Supervisor Password	Press Enter to set the supervisor password. When set, this password protects the BIOS Setup Utility from unauthorized access. The user can not either enter the Setup menu nor change the value of parameters.	
Set User Password	Press Enter to set the user password. When user password is set, this password protects the BIOS Setup Utility from unauthorized access. The user can enter Setup menu only and does not have right to change the value of parameters.	
Set Hdd Password	Enter HDD password.	
Power on password	Defines whether a password is required or not while the events defined in this group happened. The following sub-options are all requires the Supervisor password for changes and should be grayed out if the user password was used to enter setup.	Enabled or Disabled

NOTE: When you are prompted to enter a password, you have three tries before the system halts. Don't forget the password. If you forget the password, you may have to reset the computer.

Setting a Password

Follow these steps as you set the user or the supervisor password:

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Supervisor Password box appears:

A blue rectangular dialog box with a title bar at the top that says "Set Supervisor Password". Below the title bar, there are two input fields. The first field is labeled "Enter New Password" and the second is labeled "Confirm New Password". Both fields have a black rectangular cursor icon at the end of the text.

Set Supervisor Password	
Enter New Password	[]
Confirm New Password	[]

2. Type a password in the "Enter New Password" field. The password length can not exceeds 8 alphanumeric characters (A-Z, a-z, 0-9, not case sensitive). Retype the password in the "Confirm New Password" field.


IMPORTANT: Be very careful when typing your password because the characters do not appear on the screen.

3. Press **Enter**. After setting the password, the computer sets the User Password parameter to "Set".
4. If desired, you can opt to enable the Password on boot parameter.
5. When you are done, press F10 to save the changes and exit the BIOS Setup Utility.

Removing a Password

Follow these steps:

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Password box appears:

A blue rectangular dialog box with a title bar at the top that says "Set Supervisor Password". Below the title bar, there are three input fields. The first field is labeled "Enter Current Password", the second is labeled "Enter New Password", and the third is labeled "Confirm New Password". The first field has a black rectangular cursor icon at the end of the text, while the other two are empty.

Set Supervisor Password	
Enter Current Password	[]
Enter New Password	[]
Confirm New Password	[]

2. Type the current password in the Enter Current Password field and press **Enter**.
3. Press **Enter** twice **without** typing anything in the Enter New Password and Confirm New Password fields. The computer then sets the Supervisor Password parameter to "Clear".
4. When you have changed the settings, press u to save the changes and exit the BIOS Setup Utility.


Changing a Password

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Password box appears.



The image shows a BIOS screen titled "Set Supervisor Password". It has a blue background with white text. There are three input fields, each preceded by a label: "Enter Current Password", "Enter New Password", and "Confirm New Password". Each field is represented by a black rectangle inside square brackets.

2. Type the current password in the Enter Current Password field and press **Enter**.
 3. Type a password in the Enter New Password field. Retype the password in the Confirm New Password field.
 4. Press **Enter**. After setting the password, the computer sets the User Password parameter to "Set".
 5. If desired, you can enable the Password on boot parameter.
 6. When you are done, press **F10** to save the changes and exit the BIOS Setup Utility.
- If the verification is OK, the screen will display as following.



The image shows a BIOS screen titled "Setup Notice". It has a light gray background with dark gray text. The text "Changes have been saved." is centered. Below it is a black button with the word "Continue" in white.

The password setting is complete after the user presses **Enter**.

If the current password entered does not match the actual current password, the screen will show you the Setup Warning.



The image shows a BIOS screen titled "Setup Warning". It has a light gray background with red text. The text "Invalid Password." is centered. Below it is a black button with the word "Continue" in white.

If the new password and confirm new password strings do not match, the screen displays the following message.



The image shows a BIOS screen titled "Setup Warning". It has a light gray background with red text. The text "Passwords do not match. Re-enter password." is centered. Below it is a black button with the word "Continue" in white.


Boot

This menu allows the user to decide the order of boot devices to load the operating system. Bootable devices includes the USB diskette drives, the onboard hard disk drive and the DVD drive in the module bay.

InsydeH20 Setup Utility				Rev. 3.5					
Information		Main		Security		Boot		Exit	
Boot priority order: 1. IDE0 : Hitachi HTS545032B9A300 2. IDE1 : 3. Network Boot : Atheros Boot Agent 4. USB HDD 5. USB CDROM : 6. USB FDD :							Item Specific Help		
							Use <↑> or <↓> to select a device, then press <F5> to move it down the list, or <F6> to move it up the list. Press <Esc> to escape the menu		
F1 Help		↑↓ Select Item		F5/F6 Change Values		F9 Setup Default			
ESC Exit		←→ Select Menu		Enter Select ► SubMenu		F10 Save and Exit			

Exit

The Exit screen allows you to save or discard any changes you made and quit the BIOS Utility.



The table below describes the parameters in this screen.

Parameter	Description
Exit Saving Changes	Exit System Setup and save your changes to CMOS.
Exit Discarding Changes	Exit utility without saving setup data to CMOS.
Load Setup Default	Load default values for all SETUP item.
Discard Changes	Load previous values from CMOS for all SETUP items.
Save Changes	Save Setup Data to CMOS.

BIOS Flash Utility


The BIOS flash memory update is required for the following conditions:

- New versions of system programs
- New features or options
- Restore a BIOS when it becomes corrupted.

DOS Flash Utility

Perform the following steps to use the DOS Flash Utility:

1. Press F2 during boot to enter the Setup Menu.
2. Select **Boot Menu** to modify the boot priority order, for example, if using USB HDD to Update BIOS, move USB HDD to position 1.



3. Execute the **FLASH.BAT** batch file to update BIOS. Or enter C:\ **Flash it bios ver.fd/dc**
The flash process begins as shown.



4. In flash BIOS, the message **Please do not remove AC Power Source** displays.
NOTE: If the AC power is not connected, the following message displays.



Plug in the AC power to continue.

5. Flash is complete when the message Flash programming complete displays.

WinFlash Utility

Perform the following steps to use the WinFlash Utility:

1. Double click the WinFlash executable.
2. Click **OK** to begin the update. A progress screen displays.




3. When the process is complete, close all programs and applications and reboot the system.

Remove HDD/BIOS Password Utilities

This section provide you with removing HDD/BIOS method:


Remove HDD Password:

When the user keys in the wrong password three times, the system reports the following error code to user.



To unlock the HDD password, perform the following steps:

1. Press **Enter** to display the Select Item screen.



2. Select **Enter Unlock Password** and press **Enter**.


An Unlock Password displays.



3. Make a note of the key, **76943488** in the example.
4. Boot up the system to a removable bootable drive containing DOS and the UnlockHD.EXE program and open a DOS prompt. For instructions on changing boot priority see "Boot" on page 31.
5. From the DOS prompt, enter the **UnlockHD.EXE** command and input the key to create an unlock code. Make a note of the result, for example **46548274**.
6. Reboot to the hard disk and wait for the error code to reappear.
7. Press **Enter** to display the Select Item screen.
8. Select **Enter Unlock Password** and press **Enter**.
9. Enter the unlock code generated by UnlockHD.EXE.
10. Save and exit the BIOS to complete the process.

Removing BIOS Passwords:

If you key in the wrong Supervisor Password three times, System Disabled displays on the screen. See the image below.



To reset the BIOS password, run clnpwd.exe as follows:

1. From a DOS prompt, Execute **clnpwd.exe**

```
d:\Clnpwd>clnpwd
ACER Clean Password Utility V1.00
Press 1 or 2 to clean any password shown as below
      1.User Password
      2.Supervisor Password

Clean User Password Successfully!
```

2. Press 1 or 2 to clean the desired password shown on the screen.

The onscreen message determines whether the function is successful or not.

Miscellaneous Utilities

Using Boot Sequence Selector

Boot Sequence Selector allows the boot order to be changes without accessing the BIOS. To use Boot Sequence Selector, perform the following steps:

1. Enter into DOS.
2. Execute BS.exe to display the usage screen.

```
d:\B00TSEQ>bs

*** Boot Sequence Selector Version 0.03 ***
Create by Rockwell Chuang 10/01/2005.

Usage:
      BS [ 1 | 2 | 3 | 4 ]

BS 1 : [ Floppy ] => [ HardDisk ] => [ CD-ROM ] => [ LAN   ]
BS 2 : [ HardDisk ] => [ CD-ROM ] => [ LAN   ] => [ Floppy ]
BS 3 : [ CD-ROM ] => [ HardDisk ] => [ LAN   ] => [ Floppy ]
BS 4 : [ LAN   ] => [ Floppy ] => [ HardDisk ] => [ CD-ROM ]

d:\B00TSEQ>
```

3. Select the desired boot sequence by entering the corresponding sequence, for example, enter BS2 to change the boot sequence to HDD|CD ROM|LAN|Floppy.

Using DMITools

The DMI (Desktop Management Interface) Tool copies BIOS information to eeprom to be used in the DMI pool for hardware management.

When the BIOS displays **Verifying DMI pool data** it is checking the table correlates with the hardware before sending to the operating system (Windows, etc.).

To update the DMI Pool, perform the following steps:

1. Enter into DOS.
2. Execute **dmitools.exe**. The following messages show dmitools usage:

```
*** Compal DMI String R/W Utility Ver1.40 for 2006/03/14 ***

Usage:

DMITools [ /R | /WP | /WS | /WU ] [ STRING ]

[ /R ]   : Read DMI Information from Memory
[ /WM ]  : Write Manufacturer Name to EEPROM. (Max.= 16 characters)
[ /WP ]  : Write Product Name to EEPROM.      (Max.= 16 characters)
[ /WS ]  : Write Serial Number to EEPROM      (Max.= 22 characters)
[ /WU ]  : Write UUID to EEPROM.              (Ignore String      )
[ /WA ]  : Write Asset Tag to EEPROM.         (Max.= 32 characters)
```

IMPORTANT:The following write examples (2 to 5) require a system reboot to take effect

Example 1: Read DMI Information from Memory

Input:

```
dmitools /r
```

Output:

Manufacturer (Type1, Offset04h): Acer

Product Name (Type1, Offset05h): Aspire one xxxxx

Serial Number (Type1, Offset07h): 01234567890123456789

UUID String (Type1, Offset08h): xxxxxxxx-xxxx-xxxx-xxxx-xxxxxxxxxxxx

Asset Tag (Type3, Offset04h): Acer Asstag

Example 2: Write Product Name to EEPROM

Input:

```
dmitools /wp Acer
```

Example 3: Write Serial Number to EEPROM

Input:

```
dmitools /ws 01234567890123456789
```

Example 4: Write UUID to EEPROM

Input:

```
dmitools /wu
```

Example 5: Write Asset Tag to EEPROM


Input:

```
dmitools /wa Acer Asstag
```

Using the LAN MAC Utility

Perform the following steps to write MAC information to eeprom:

1. Use a text editor, for example Notepad, to edit the MAC.CFG file as shown:



- WriteData= '001122334455' <----- MAC value
 - StartAddr=7A <----- MAC address
 - WriteLeng=6 <----- MAC value length
 - KeepByte=0 <----- can be any value
2. Boot into DOS.
 3. Execute **MAC.BAT** to write MAC information to eeprom.

Machine Disassembly and Replacement

This chapter contains step-by-step procedures on how to disassemble the notebook computer for maintenance and troubleshooting.

Disassembly Requirements

To disassemble the computer, you need the following tools:

- Wrist grounding strap and conductive mat for preventing electrostatic discharge
- Flat screwdriver
- Philips screwdriver
- Plastic flat screwdriver
- Plastic tweezers

NOTE: The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components.

Related Information

The product previews seen in the disassembly procedures may not represent the final product color or configuration.

IMPORTANT: Cable paths and positioning may not represent the actual model. During the removal and replacement of components, ensure all available cable channels and clips are used and that the cables are replaced in the same position.

Replacement Requirements

NOTE: Cabling and components require adhesive to be applied during the replacement and reassembly process.

NOTE: During manufacture a cyanoacrylate glue is used provided by Holdtite Adhesives LTD. This is not a specified requirement. The reassembler is free to select an alternative appropriate adhesive.

Pre-disassembly Instructions

Before proceeding with the disassembly procedure, make sure that you do the following:

1. Turn off the power to the system and all peripherals.
2. Unplug the AC adapter and all power and signal cables from the system.



3. Place the system on a flat, stable surface.

Disassembly Process

The disassembly process is divided into the following sections:

- External components disassembly
- Main unit disassembly
- LCD module disassembly

The flowcharts provided in the succeeding disassembly sections illustrate the entire disassembly sequence. Observe the order of the sequence to avoid damage to any of the hardware components. For example, if you want to remove the Mainboard, you must first remove the Keyboard, and LCD Module then disassemble the inside assembly frame in that order.

Main Screw List

Screw	Quantity	Acer Part Number
M2.0X2.5-I(BNI)(NYLOK) IRON	4	86.SA107.002
M2*3.0 I (BNI,NYLOK)IRON	16	86.SA107.001
M2*5-I(BZN)(NYLOK)	20	86.TG607.004


External Module Disassembly Process

NOTE: The product previews seen in the disassembly procedures may not represent the final product color or configuration.

Screw List

Step	Screw	Quantity	Part No.
WAN Module Disassembly	2*3	1	86.SA107.001

External Modules Disassembly Flowchart



Removing the Battery Pack

1. Turn the computer over.
2. Slide the battery lock/unlock latch to the unlock position.



3. Slide and hold the battery release latch to the release position (1), then slide out the battery pack from the main unit (2).



Removing the Dummy Card

1. Press the dummy card in to allow it to spring out.



2. Pull the dummy card out.




Removing the Hard Disk Drive Module

DISCLAIMER: The notebook sample in the following images shows an FFC. The actual model includes an FPC as pictured in the image on the right.



1. See “Removing the Battery Pack” on page 45.
2. Loosen the four captive screws.



3. Lift the HDD cover up and away by the corner.



4. Grasp the FPC cable and lift to remove.



NOTE: The cable pictured in the following images may differ from the actual sample.



-
5. Grasp the plastic tab at the top of the HDD and lift to bring the HDD out of its bay. At the same time, hold the HDD with the other hand and lift to remove from the chassis.




6. Unlock the HDD FPC and pull the FPC away.



Removing the DIMM Module


1. See “Removing the Battery Pack” on page 45.
2. Loosen the four captive screws in the memory cover.



3. Lift the memory cover away.



4. Push outwards the memory module clips.




-
5. Pull the memory module out.



Removing the WLAN Module

1. See “Removing the Battery Pack” on page 45..
2. Loosen the four captive screws in the memory cover.



3. Lift and remove the memory cover.



4. Detach the two cables from the Wireless LAN module.

IMPORTANT: Take note of the Main (1. black) and Auxiliary (2. white) connectors.




5. Remove the one screw. Ensure the cables are well clear of the module



Screw List

Step	Screw	Quantity	Screw Type
WAN Module Disassembly	2*3	1	

6. Pull the WLAN module out and away.




Main Unit Disassembly Process

IMPORTANT: Cable paths and positioning may not represent the actual model. During the removal and replacement of components, ensure all available cable channels and clips are used and that the cables are replaced in the same position.

NOTE: The product previews seen in the disassembly procedures may not represent the final product color or configuration.

Main Unit Disassembly Flowchart



Screw List

Step	Screw	Quantity	Part No.
Remove Upper Cover	M2*3	3	86.SA107.001
	M2*5	18	86.TG607.004
Remove Button Board	M2*3	2	86.W4107.002
Remove LCD Module	M2*5	2	86.TG607.004
Remove LED Board	M2*3	1	86.SA107.001
Remove I/O Board	M2*3	1	86.SA107.001
Remove Mainboard	M2*3	4	86.SA107.001

Removing the Keyboard

IMPORTANT: The keyboard is easily warped or damaged during the removal process. Take care not to use excessive force when removing to prevent damage.

1. See “Removing the Battery Pack” on page 45.
2. See “Removing the Hard Disk Drive Module” on page 47.
3. See “Removing the DIMM Module” on page 49.
4. See “Removing the WLAN Module” on page 51.
5. Using the plastic pry, press in the four latches along the top of the keyboard to release the keyboard from the cover.

NOTE: The keyboard will spring up slightly when all retaining clips are unlocked.




-
6. Using the plastic pry, lift up the top edge of the keyboard and then lift the keyboard up.




7. Flip the keyboard over.

a. Unlock the FCC




b. Pull the keyboard away




Removing the Upper Cover

- 1. See “Removing the Keyboard” on page 55.
- 2. Disconnect the button board FCC from the main board by unlocking the FCC cable and pulling away.




- 3. Remove the nine screws in the upper cover.



Screw List

Step	Size	Quantity	Screw Type
Upper Cover Disassembly	M2*3	3 (blue call out)	
	M2*5	6 (red call out)	


4. Turn the computer over and remove the twelve screws in the bottom cover.



Screw List

Step	Size	Quantity	Screw Type
Upper Cover Disassembly	M2*5	12	


5. Turn the computer over and grasp the upper cover under the top edge. Then pull the upper cover up and away from the computer.




Removing the Button Board

IMPORTANT: The Touchpad Board cannot be removed individually. To replace the Touchpad, replace the entire Upper Cover.


1. See “Removing the Upper Cover” on page 57.
2. Unlock and remove the touch-pad to mainboard FCC.



3. Unlock and detach the touch-pad to touch-pad FCC.




4. Remove the two screws holding the button board.




Screw List

Step	Size	Quantity	Screw Type
Button board	M2*3	2	

5. Lift the button board away




6. Peel the touch-pad FCC away from the adhesive.



7. Unlock the touch-pad FCC and pull the cable away.




-
8. Lift up and pull the button board to main board FCC free.




Removing the LCD Module


1. See “Removing the Upper Cover” on page 57.
2. Pull the WLAN cables through and away from the computer.



3. Lift the transparent adhesive tape off the LCD connector.



4. Push out the LCD connector.




5. Remove the two screws of the LCD module hinges.



Screw List


Step	Screw	Quantity	Screw Type
LCD Module Disassembly	M2*5	2	

6. Lift the LCD module away.




Removing the LED Board

- 1. See “Removing the Upper Cover” on page 57.
- 2. Unlock and remove the LCD board FCC.




- 3. Remove the single screw securing the LED Board to the Lower Cover.




Screw List

Step	Screw	Quantity	Screw Type
LED Board Disassembly	2*3	1	

-
4. Lift off the LCD Board.




5. Unlock and remove the LED board FCC from the mainboard.





Removing the Bluetooth Module


1. See “Removing the Upper Cover” on page 57.
2. Detach the Bluetooth module cable from the mainboard.



3. Lift the Bluetooth module away from the computer.




4. Detach the Bluetooth module cable from the module.




Removing the I/O Board

1. See “Removing the Upper Cover” on page 57..
2. Unlock and remove the I/O board FCC from the main board



3. Unlock and remove the I/O board FCC from the I/O board.




4. Remove the one screw from the I/O board.



Screw List


Step	Screw	Quantity	Screw Type.
I/O Board Disassembly	M2*3	1	

5. Lift the board up from the internal edge and then pull away diagonally.




Removing the Mainboard

- 1. See “Removing the Upper Cover” on page 57.
- 2. See “Removing the LCD Module” on page 62.
- 3. See “Removing the LED Board” on page 64.
- 4. See “Removing the Bluetooth Module” on page 66.
- 5. See “Removing the I/O Board” on page 67.
- 6. Disconnect the speaker cable from the mainboard.



- 7. Remove the four screws of the main board and the CRT board.




Screw List

Step	Screw	Quantity	Screw Type.
Main Board Disassembly	2*3	4	


-
8. Lift the main board and the CRT board out together. Lift the internal edge up first then pull out the external connector edge.

NOTE: The hand in the photograph holding on to the CRT board.




Removing the CRT Board

1. See “Removing the Mainboard” on page 69.
2. Disconnect the CRT cable from the CRT board.




3. Disconnect the CRT cable from the main board.




Removing the Thermal Module


1. See “Removing the Mainboard” on page 69.
2. See “Removing the CRT Board” on page 71.
3. Remove the five captive screws of the thermal module.



4. Lift the thermal module up slightly and then disconnect the thermal module cable from the main board.




5. Lift the thermal module away from the main board.



Removing the RTC Battery


IMPORTANT: Observe local regulations in the disposal of all batteries.

1. See “Removing the Mainboard” on page 69.
2. Pry the RTC battery out of the holding clips.




Removing the Speaker Modules

1. See “Removing the Mainboard” on page 69.
2. Remove the tape from the speaker cable.



3. Lift the modules away.

NOTE: The modules have adhesive on the base and may require force to free.




LCD Module Disassembly Process

IMPORTANT: Cable paths and positioning may not represent the actual model. During the removal and replacement of components, ensure all available cable channels and clips are used and that the cables are replaced in the same position.

NOTE: The product previews seen in the disassembly procedures may not represent the final product color or configuration.

LCD Module Disassembly Flowchart



Screw List

Step	Screw	Quantity	Part No.
Remove LCD Brackets	2*2.5	4	86.SA107.002
Remove LCD Panel	2*3	4	86.SA107.001

Removing the LCD Bezel

1. See “Removing the LCD Module” on page 62.
2. Pry the bezel away from the top and then work down one side, along the bottom, then up the other side.




3. Roll the bezel up and away from the hinges.




Removing the Camera Board

1. See “Removing the LCD Bezel” on page 76.
2. Disconnect the camera connector.




3. Pull up the camera board.



Removing the LCD Panel

- 1. See “Removing the Camera Board” on page 77.
- 2. Pull up the microphone.



- 3. Remove the four screws.



Screw List


Step	Screw	Quantity	Screw Type
LCD Panel Disassembly	2x3	4	

-
4. Lift the LCD panel out lifting the bottom of the panel first.



Removing the LCD Brackets

- 1. See “Removing the LCD Panel” on page 78.
- 2. Remove the four LCD bracket screws.




Screw List


Step	Screw	Quantity	Screw Type
LCD Brackets Disassembly	M2*2.5	4	

Removing the FPC Cable


1. See “Removing the LCD Panel” on page 78.
2. Place the panel face down on a clean smooth surface. Pull the microphone/camera cable off the adhesive.



3. Lift up the protective plastic tab.





4. Disconnect the LCD connector.



Removing the Antennas



1. See “Removing the LCD Panel” on page 78.
2. Lift up the right antenna and pull the cable away from the LCD module.



3. Lift up the left antenna and pull the cable away from the LCD module.



4. Pull up the two adhesive foil tabs from the cables.



-
5. Remove the antennas completely.




LCD Reassembly Procedure

NOTE: Adhesive is required to be added at various steps to cables and components. Locations of adhesive to be added is designated with a: ●


NOTE: During manufacture a cyanoacrylate glue is used provided by Holdtite Adhesives LTD. This is not a specified requirement. The reassembler is free to select an alternative appropriate adhesive.

Replacing the Antennas


1. Relay the cables around the module edge for the left antenna.



2. Relay the cables around the module edge for the right antenna.



-
3. Stick the two antennas down pressing firmly.




4. Stick down the two foil tabs ensuring the screw holes are properly aligned.



Replacing the FPC Cable


1. Connect the FPC cable connector.



2. Place the protective clear adhesive tape down firmly over the connector.



3. Apply adhesive behind the cable and stick the FPC cable down on the rear of the panel.



Replacing the LCD Brackets

- 1. Replace the four screws holding the LCD brackets in place.




Screw List

Step	Screw	Quantity	Screw Type
LCD Brackets Disassembly	M2*2.5	4	

Replacing the LCD Panel

- 1. Place the LCD panel into LCD module as shown top edge first, making sure the cable is not trapped behind the panel.




- 2. Replace the four screws while ensuring the cables pass through the hinges correctly.



Screw List


Step	Screw	Quantity	Screw Type
LCD Panel Assembly	2x3	4	

-
3. Apply adhesive and stick the microphone down.




Replacing the Camera Board

1. Apply adhesive and lay the Camera Board board down pressing firmly.



2. Connect the cable to the Camera Board.



Replacing the LCD Bezel

1. Place the bezel hinge covers over the hinges.



2. Ensure the cables are correctly exiting the hinges.




-
3. Press down around the bezel starting from the bottom and working simultaneously around the edges to the top.




Main Unit Reassembly Process

Replacing the Speaker Modules


1. Apply adhesive in two places under the speaker modules.



2. Press down firmly on the two speaker modules.




3. Place tape over the speaker module cables.




Replacing the RTC Battery

1. Place the RTC battery into the holding clips on the main board.




Replacing the Thermal Module

1. Connect the thermal module connector to the main board.




2. Place the Thermal Module onto the main board. Then first tighten the three captive screws marked 1, 2, 3 on the thermal module in order: 1-2-3. First tighten Screw 1, then screw 2, then screw 3.




IMPORTANT: Incorrect order of screw replacement could harm the CPU.

3. The tighten the other two captive screws




Replacing the CRT Board


1. Connect the CRT board cable to the main board.



2. Connect the CRT board cable to the CRT board.




3. Align the CRT board cable carefully between the main board and the CRT board and stick down the attached tape of the cable.



Replacing the Main Board

- 1. Slide the main board external connector edge in first to the lower case.




- 2. Replace the four screws to secure the mainboard to the lower cover.



Screw List


Step	Screw	Quantity	Screw Type
Main Board Assembly	2x3	4	

3. Connect the speaker connector.




Replacing the I/O Card

- 1. Place the I/O card into the lower case edge first.




- 2. Replace the one screw.




Screw List

Step	Screw	Quantity	Screw Type
I/O Card Assembly	2x3	1	

3. Connect and lock the I/O card FCC to the I/O board.




4. Connect and lock the I/O card FCC to the main board.




Replacing the Bluetooth Module


1. Connect the Bluetooth module cable to the Bluetooth module.



2. Apply adhesive and place the Bluetooth module into place pressing down firmly.





3. Connect the Bluetooth module cable to the main board.




Replacing the LED Board


1. Connect and lock the LED board FCC to the mainboard.



2. Place the LED board into place ensuring the slide switches on the front are properly aligned in the lower cover slots.




3. Replace the one screw.



Screw List

Step	Screw	Quantity	Screw Type
LED Board Assembly	M2*3	1	

4. Connect the LED board FCC to LED board.




Replacing the LCD Module

- 1. Place the LCD module hinges into position on the lower case.




- 2. Replace the two screws.




Screw List

Step	Screw	Quantity	Screw Type
LCD Module Assembly	M2x5	2	

-
3. Reconnect the LCD module connector.



4. Press the adhesive plastic tape of the LCD module connector down firmly.




-
5. Relay the WLAN cables around and through the lower case.




Replacing the Button Board


1. Put the button board to main board FCC through the upper cover and lay out correctly.




2. Apply adhesive and stick the touch pad FCC down onto the upper cover.



3. Connect the touch pad FCC to the touch pad.




4. Place the button board onto the upper cover and replace the two screws.



Screw List

Step	Screw	Quantity	Screw Type
Button Board Assembly	M2*3	2	


5. Connect and lock the touch pad FCC to the button board.



-
6. Lay the button board FCC down carefully on the upper cover.




7. Connect the button board FCC to the button board.




Replacing the Upper Cover

1. Place the upper cover onto the lower cover aligning the hinges first and then press down around the edges.




2. Replace the nine screws.



Screw List

Step	Size	Quantity	Screw Type
Upper Cover Assembly	M2*3	3 (blue call out)	
	M2*5	6 (red call out)	


3. Turn the computer over and replace the bottom cover twelve screws.



Screw List


Step	Size	Quantity	Screw Type
Upper Cover Assembly	M2*5	12	

4. Turn the computer back over and connect the button board FCC to the main board.



Replacing the Keyboard

1. Connect the FCC to the mainboard.



2. Turn the keyboard over and insert the bottom edge in push down ensure the four latches across the top are fully secured.



Replacing the Wireless LAN Module

- 1. Place the wireless LAN module into its connector.




- 2. Replace the one screw.



Screw List


Step	Size	Quantity	Screw Type
WLAN Assembly	M2*3	1	

-
3. Replace the connectors. The white (Aux) cable attaches to the connector marked **2** on the board. The black (Main) cable attaches to the connector marked **1** on the board.



Replacing the DIMM Module


1. Slide the DIMM module into the connector and press down till the locking springs click into place.



2. Place the DIMM module door down edge first.



3. Tighten the four captive screws.




Replacing the Hard Disk Drive

DISCLAIMER: The notebook sample in the following images shows an FFC. The actual model includes an FPC as pictured in the image on the right.



1. Connect the HDD FPC to the HDD.



2. Lift up the clear plastic tab and place the HDD into its bay.



3. Connect the HDD FPC to the main board.




NOTE: The cable pictured in the above images may differ from the actual sample.

-
4. Place the HDD cover in from one edge.



5. Tighten the four captive screws.



Replacing the Battery

1. Slide the battery into position.



2. Close the locking latch.



Replace the Dummy Card

Push the dummy card into the slot until it clicks into place.



Troubleshooting

Common Problems

Use the following procedure as a guide for computer problems.

NOTE: The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.


1. Obtain the failing symptoms in as much detail as possible.
2. Verify the symptoms by attempting to re-create the failure by running the diagnostic test or by repeating the same operation.
3. Use the following table with the verified symptom to determine which page to go to.

Symptoms (Verified)	Go To
Power On Issue	Page 122
No Display Issue	Page 123
LCD Failure	Page 125
Internal Keyboard Failure	Page 126
TouchPad Failure	Page 127
Internal Speaker Failure	Page 128
Internal Microphone Failure	Page 129
USB Failure	Page 131
Other Function Failure	Page 131

4. If the Issue is still not resolved, see "Online Support Information" on page 165.

Power On Issue

If the system doesn't power on, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:




Computer Shuts down Intermittently

If the system powers off at intervals, perform the following actions one at a time to correct the problem.

1. Check the power cable is properly connected to the computer and the electrical outlet.
2. Remove any extension cables between the computer and the outlet.
3. Remove any surge protectors between the computer and the electrical outlet. Plug the computer directly into a known good electrical outlet.
4. Remove all external and non-essential hardware connected to the computer that are not necessary to boot the computer to the failure point.
5. Remove any recently installed software.
6. If the Issue is still not resolved, see "Online Support Information" on page 165.

No Display Issue

If the **Display** doesn't work, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



No POST or Video

If the POST or video doesn't display, perform the following actions one at a time to correct the problem.

1. Make sure that the internal display is selected. On this notebook model, switching between the internal display and the external display is done by pressing **Fn+F5**. Reference Product pages for specific model procedures.
2. Make sure the computer has power by checking at least one of the following occurs:
 - Fans start up
 - Status LEDs light up

If there is no power, see “Power On Issue” on page 122.

3. Drain any stored power by removing the power cable and battery and holding down the power button for 10 seconds. Reconnect the power and reboot the computer.
4. Connect an external monitor to the computer and switch between the internal display and the external display is by pressing **Fn+F5** (on this model).

If the POST or video appears on the external display, see “LCD Failure” on page 125.

5. Disconnect power and all external devices including port replicators or docking stations. Remove any memory cards and CD/DVD discs. Restart the computer.

If the computer boots correctly, add the devices one by one until the failure point is discovered.

6. Reseat the memory modules.
7. Remove the drives (see “Disassembly Process” on page 34).
8. If the Issue is still not resolved, see “Online Support Information” on page 165.

Abnormal Video Display

If video displays abnormally, perform the following actions one at a time to correct the problem.

1. Reboot the computer.
2. If permanent vertical/horizontal lines or dark spots display in the same location, the LCD is faulty and should be replaced. See “Disassembly Process” on page 34.
3. If extensive pixel damage is present (different colored spots in the same locations on the screen), the LCD is faulty and should be replaced. See “Disassembly Process” on page 34.
4. Adjust the brightness to its highest level. See the User Manual for instructions on adjusting settings.
NOTE: Ensure that the computer is not running on battery alone as this may reduce display brightness.

If the display is too dim at the highest brightness setting, the LCD is faulty and should be replaced. See “Disassembly Process” on page 34.

5. Check the display resolution is correctly configured:
 - a. Minimize or close all Windows.
 - b. If display size is only abnormal in an application, check the view settings and control/mouse wheel zoom feature in the application.
 - c. If desktop display resolution is not normal, right-click on the desktop and select **Personalize→ Display Settings**.
 - d. Click and drag the Resolution slider to the desired resolution.
 - e. Click **Apply** and check the display. Readjust if necessary.
6. Roll back the video driver to the previous version if updated.
7. Remove and reinstall the video driver.
8. Check the Device Manager to determine that:
 - The device is properly installed. There are no red Xs or yellow exclamation marks.
 - There are no device conflicts.
 - No hardware is listed under Other Devices.
9. If the Issue is still not resolved, see “Online Support Information” on page 165.
10. Run the Windows Memory Diagnostic from the operating system DVD and follow the onscreen prompts.
11. If the Issue is still not resolved, see “Online Support Information” on page 165.

Random Loss of BIOS Settings


If the computer is experiencing intermittent loss of BIOS information, perform the following actions one at a time to correct the problem.

1. If the computer is more than one year old, replace the CMOS battery.
2. Run a complete virus scan using up-to-date software to ensure the computer is virus free.
3. If the computer is experiencing HDD or ODD BIOS information loss, disconnect and reconnect the power and data cables between devices.
If the BIOS settings are still lost, replace the cables.
4. If HDD information is missing from the BIOS, the drive may be defective and should be replaced.
5. Replace the Motherboard.

6. If the Issue is still not resolved, see “Online Support Information” on page 165.


LCD Failure

If the **LCD** fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:




Built-In Keyboard Failure

If the built-in **Keyboard** fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:




TouchPad Failure

If the **TouchPad** doesn't work, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



Internal Speaker Failure

If the internal **Speakers** fail, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



Sound Problems

If sound problems are experienced, perform the following actions one at a time to correct the problem.


1. Reboot the computer.
2. Navigate to **Start** → **Control Panel** → **System and Maintenance** → **System** → **Device Manager**. Check the Device Manager to determine that:
 - The device is properly installed.
 - There are no red Xs or yellow exclamation marks.
 - There are no device conflicts.
 - No hardware is listed under Other Devices.
3. Roll back the audio driver to the previous version, if updated recently.
4. Remove and reinstall the audio driver.
5. Ensure that all volume controls are set mid range:
 - a. Click the volume icon on the taskbar and drag the slider to 50. Ensure that the volume is not muted.
 - b. Click Mixer to verify that other audio applications are set to 50 and not muted.
6. Navigate to **Start** → **Control Panel** → **Hardware and Sound** → **Sound**. Ensure that Speakers are selected as the default audio device (green check mark).

NOTE: If Speakers does not show, right-click on the **Playback** tab and select **Show Disabled Devices** (clear by default).
7. Select Speakers and click **Configure** to start **Speaker Setup**. Follow the onscreen prompts to configure the speakers.

8. Remove and recently installed hardware or software.
9. Restore system and file settings from a known good date using **System Restore**.
If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
10. Reinstall the Operating System.
11. If the Issue is still not resolved, see “Online Support Information” on page 165.

Internal Microphone Failure

If the internal **Microphone** fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



Microphone Problems

If internal or external **Microphones** do not operate correctly, perform the following actions one at a time to correct the problem.

1. Check that the microphone is enabled. Navigate to **Start**→ **Control Panel**→ **Hardware and Sound**→ **Sound** and select the **Recording** tab.
2. Right-click on the **Recording** tab and select **Show Disabled Devices** (clear by default).
3. The microphone appears on the **Recording** tab.
4. Right-click on the microphone and select **Enable**.
5. Select the microphone then click **Properties**. Select the **Levels** tab.
6. Increase the volume to the maximum setting and click **OK**.
7. Test the microphone hardware:
 - a. Select the microphone and click **Configure**.
 - b. Select **Set up microphone**.

-
- c. Select the microphone type from the list and click **Next**.
 - d. Follow the onscreen prompts to complete the test.
8. If the Issue is still not resolved, see “Online Support Information” on page 165.

HDD Not Operating Correctly

If the **HDD** does not operate correctly, perform the following actions one at a time to correct the problem.

1. Disconnect all external devices.
2. Run a complete virus scan using up-to-date software to ensure the computer is virus free.
3. Run the Windows Vista Startup Repair Utility:
 - a. insert the Windows Vista Operating System DVD in the ODD and restart the computer.
 - b. When prompted, press any key to start to the operating system DVD.
 - c. The **Install Windows** screen displays. Click **Next**.
 - d. Select **Repair your computer**.
 - e. The **System Recovery Options** screen displays. Click **Next**.
 - f. Select the appropriate operating system, and click **Next**.

NOTE: Click **Load Drivers** if controller drives are required.

- g. Select **Startup Repair**.
- h. Startup Repair attempts to locate and resolve issues with the computer.
- i. When complete, click **Finish**.


If an issue is discovered, follow the onscreen information to resolve the problem.

4. Run the Windows Memory Diagnostic Tool. For more information see Windows Help and Support.
5. Restart the computer and press F2 to enter the BIOS Utility. Check the BIOS settings are correct and that CD/DVD drive is set as the first boot device on the Boot menu.
6. Ensure all cables and jumpers on the HDD and ODD are set correctly.
7. Remove any recently added hardware and associated software.
8. Run the Windows Disk Defragmenter. For more information see Windows Help and Support.
9. Run Windows Check Disk by entering **chkdsk /r** from a command prompt. For more information see Windows Help and Support.
10. Restore system and file settings from a known good date using **System Restore**.

If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
11. Replace the HDD. See “Disassembly Process” on page 34.

USB Failure (Right up/down side)

If the rightside **USB** port fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



Other Failures

If the VGA board, LAN Port, external MIC or Speakers, PCI Express Card, 5-in-1 Card Reader or Volume Wheel fail, perform the following general steps to correct the problem. Do not replace non-defective FRUs:

1. Check whether the drive is OK.
2. Verify that the Test Fixture is ok.
3. Swap the mainboard and retest.

Intermittent Problems

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

1. Run the advanced diagnostic test for the system board in loop mode at least 10 times.
2. If no error is detected, do not replace any FRU.
3. If any error is detected, replace the FRU. Rerun the test to verify that there are no more errors.

Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative.

Follow these procedures to isolate the failing FRU (do not isolate non-defective FRU).

NOTE: Verify that all attached devices are supported by the computer.

NOTE: Verify that the power supply being used at the time of the failure is operating correctly. (See “Power On Issue” on page 122.):

1. Power-off the computer.
2. Visually check them for damage. If any problems are found, replace the FRU.
3. Remove or disconnect all of the following devices:
 - Non-Acer devices
 - Printer, mouse, and other external devices
 - Battery pack
 - Hard disk drive
 - DIMM
 - CD-ROM/Diskette drive Module
 - PC Cards
4. Power-on the computer.
5. Determine if the problem has changed.
6. If the problem does not recur, reconnect the removed devices one at a time until you find the failing FRU.
7. If the problem remains, replace the following FRU one at a time. Do not replace a non-defective FRU:
 - System board
 - LCD assembly

POST Code Reference Tables

These tables describe the POST codes and components of the POST process.

POST Routine Description	Code
PeiEventLog	01
OemServices	02
SioInit	03
MonoStatusCode	04
PentiumMCpuPeim	08
PlatformStage1	09
Variable	0A
IchInit	0B
PlatformStage2	0D
IchSmbusArpDisabled	0E
ClockGen	12
OpPresence	13
TcgPei	14
FindFv	15
DxeIpl	2F
LightMemoryInit	10
S3ResumeSoftSmi	11
Crc32SectionExtract	31
OemServices	A4
EventLog	A5
ScriptSave	32
AcpiS3Save	33
SmartTimer	34
JpegDecoder	35
PcxDecoder	36
PlatformBds	8A
MpCpu	37
LegacyMetronome	38
FtwLite	39
Runtime	3A
MonotonicCounter	3B
WatchDogTimer	3C
SecurityStub	3D
Cpulo	3E
Cf9Reset	3F
PcRtc	40
StatusCode	41
Variable	42
SmmVariable	CF
EmuVariable	43


POST Routine Description	Code
TcgDxe	A2
PhysicalPresence	A3
TpmDriver	AE
TcgSmm	AE
PhysicalPresenceReadyToBoot	AE
DataHubRecordPolicy	AD
Undi	86
SNP	90
BC	91
PxeDhcp4	92
Ebc	93
IsaBus	4D
IsaSerial	4E
Ps2Mouse	6D
IdeBus	4F
LightPciBus	50
UsbBot	6E
UsbCbi0	6F
UsbCbi1	70
UsbKb	71
UsbMassStorage	72
UsbMouse	74
Ehci	8F
Uhci	73
UsbBus	75
SmmBase	C2
SmmDisp	C5
SmmReloc	C4
SmmRuntime	C7
SmmThunk	C9
OemServices	D8
ChipsetInit	44
SmmAccess	C0
PciHostBridge	46
PciExpress	47
GmchMbi	CD
IchInit	48
IdeController	49
SataController	4A
IchSmbusLight	4B
SmmControl	C1
Ich7MSmmDispatcher	C8
IsaAcpiDriver	4C

POST Routine Description	Code
Fwh	52
SmmFwh	CE
PciHotPlug	54
BootOptionPolicy	51
SetupUtility	76
Platform	55
PlatformIde	56
Ppm	D9
Platform	CC
Ihisi	D0
SetupMouse	f9
Int15Microcode	D1
SmmPnp	D2
Smbios	57
MemorySubClass	58
MiscSubclassDriver	59
SysPassword	AB
PswdConsole	AC
HddPswdServiceBody	D7
HddPswdService	A6
HiiDatabase	80
OemSetupBrowser	82
Font(English)	7E
Font(French)	7F
Font(Chinese)	8D
UnicodeCollation	B1
ConPlatform	5A
ConSplitter	5D
GraphicsConsole	79
Terminal	7A
VgaClass	5E
SaveMemoryConfig	5B
AcpiSupport	5C
AcpiPlatform	53
DataHub	5F
DataHubStdErr	7B
GenericMemoryTest	61
DiskIo	60
Fat	7C
Partition	7D
PciPlatform	6B
AlertStandardForma	45
PciSerial	A8

POST Routine Description	Code
AsfInit	A7
IdeRController	A9
Legacy8259	63
LegacyRegion	64
LegacyInterrupt	65
BiosKeyboard	66
BiosVideo	67
MonitorKey	68
LegacyBios	69
LegacyBiosPlatform	6A
LegacyMouse	77
SmmUsbLegacy	78
AmtbxInvoke	AA
OemBadgingSupport	83

Jumper and Connector Locations


Mainboard Top View



Item	Description	Item	Description
PJ1	DC-in	CN6	Bluetooth Connector
CN3	LCD connector	U9	Clock Generator
JSIM2	SIM card connector	CN2	LED board connector
PJ2	Battery connector	CN17	USB connector
U12	EC Winbond	CN18	HDMI
U14	Codec	U2	HDMI level shift
CN8	Card reader board connector	CN4	Keyboard connector
CN7	Speaker Connector	CN5	Touch Pad connector

Mainboard Bottom View

BOTTOM SIDE



Item	Description	Item	Description
CN10	DDR2 DIMM2	CN14	RTC
CN12	DDR2 DIMM1	U19	SB ICH9M
U18	CPU	CN13	Mini Card
U17	NB GS45	CN11	Mini Card (WLAN)
CN16	Fan	CN9	HDD

Clearing Password Check and BIOS Recovery

This section provides a procedure for clearing the password and BIOS. The Hardware Open Gap on the main board clears the CMOS of all user settings and restores factory defaults.


Mainboard CMOS Discharge

Discharging the CMOS clears all user settings.

1. Disassemble the notebook and take out the Mainboard. See “Removing the Mainboard” on page 69.
2. Remove the RTC battery. See “Removing the RTC Battery” on page 73.



3. Turn the mainboard over and short the G2 pad.



4. Reconnect the RTC battery and reassemble the unit.

BIOS Recovery by Crisis Disk

BIOS Recovery Boot Block

The BIOS Recovery Boot Block is a special block of BIOS. It is used to boot up the system with minimum BIOS initialization. Users can enable this feature to restore the BIOS firmware to the factory settings if a BIOS flash process fails.

BIOS Recovery Hotkey

The system provides a function hotkey: **Fn+Esc**, to enable the BIOS Recovery process when a system is powered on during BIOS POST. To use this function, it is strongly recommended to have the AC adapter and Battery present. If this function is enabled, the system will force the BIOS to enter a special BIOS block, called Boot Block.

Steps for BIOS Recovery from USB Storage

Before performing this procedure, prepare a Crisis USB key. The Crisis USB key can be made by executing the Crisis Disk program in a functioning system with a Windows XP or Vista OS.

IMPORTANT: The Crisis Disk program will overwrite all data on any drive that you use as a crisis disk.

Follow the steps below:

1. Modify the archive name from "zh7 bios" to "ZH7X64.fd"
2. Save ROM file (file name: **ZH7X64.fd**) to the root directory of the USB storage.
3. Plug the USB storage into a USB port.
4. Press **Fn + ESC** button then plug in AC.
The Power button flashes once.
5. Press **Power** button to initiate system CRISIS mode.
When CRISIS is complete, the system auto restarts with a workable BIOS.
6. Update the latest version BIOS for this machine by the regular BIOS flashing process.

FRU (Field Replaceable Unit) List


This chapter gives you the FRU (Field Replaceable Unit) listing in global configurations of the computer. Refer to this chapter whenever ordering for parts to repair or for RMA (Return Merchandise Authorization).

Please note that WHEN ORDERING FRU PARTS, you should check the most up-to-date information available on your regional web or channel. For whatever reasons a part number change is made, it will not be noted on the printed Service Guide. For ACER AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code from those given in the FRU list of this printed Service Guide. You MUST use the local FRU list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

NOTE: To scrap or to return the defective parts, you should follow the local government ordinance or regulations on how to dispose it properly, or follow the rules set by your regional Acer office on how to return it.

Packard Bell dot Exploded Diagrams

Main Assembly




Item	Description	Part Number
1	K/B	KB.I110G.026*
2	Top Sub Assy	60.WF807.001
3	Bluetooth Cable Assy	50.SA107.001
4	FCC LED Cable	50.SA107.001
5	CRT Board Assy	50.SA107.001

Item	Description	Part Number
6	LED Board Assy	55.WF807.001
7	CRT Cable Assy	55.WF807.001
8	Main Board	MB.SA506.001*
9	Thermal Module UMA Assy	60.SA107.006
10	Base Sub Assy	60.WF807.002
11	RAM	KN.2GB03.011*
12	RAM Door Assy	42.WF807.001
13	Touch Pad Board Assy	55.WF807.004
14	Bluetooth Module	BH.21100.004
15	Cardreader Cable FCC	50.SA107.003
16	Battery	BT.00607.106*
17	LAN Board Assy	55.WF807.003
18	SD Dummy Card	42.WF807.003
19	HDD	KH.16001.042*
20	HDD Mylar	TBD
21	Cable FPC HDD	50.SA107.006
22	WLAN Card	NI.23600.046*
23	Rubber Base	47.WF807.002
24	HDD Door Assy	42.WF807.002

NOTE: Part numbers may be different depending on your model. Please refer to the FRU List for a full listing of part numbers.

LCD Assembly



Item	Description	Part Number
1	LCD Bezel	60.BD807.003
2	LCD Cover	60.BD807.001*
3	LCD Bracket-R	60.BD807.003
4	LCD Bracket-L	33.WF807.001
5	LCD Panel	LK.11605.001*
6	Camera	57.S6507.002*
7	LCD Cable w/Microphone	50.SA107.005

NOTE: Part numbers may be different depending on your model. Please refer to the FRU List for a full listing of part numbers.

FRU List

CATEGORY	PARTNAME	ACER P/N.
ADAPTER		
	ADAPTER DELTA 30W 19V 1.7X5.5X11 BLACK ADP-30JH BA LF	AP.03001.001
	ADAPTER LITE-ON 30W 1.7X5.5X11 BLACK PA-1300-04AC LF	AP.03003.001
	ADAPTER HIPRO 30W 19V 1.7X5.5X11 BLACK HP-A0301R3 B1LF LF	AP.0300A.001
BATTERY		
	Battery SIMPLO UM-2009E Li-Ion 3S2P PANASONIC 6 cell 4400mAh Main COMMON ID:UM09E71	BT.00607.106
	Battery SIMPLO UM-2009E Li-Ion 3S2P SAMSUNG 6 cell 4400mAh Main COMMON ID:UM09E75	BT.00607.107
	Battery SANYO UM-2009E Li-Ion 3S2P SANYO 6 cell 5600mAh Main COMMON ID:UM09E36	BT.00603.096
	Battery SIMPLO UM-2009E Li-Ion 3S2P SAMSUNG 6 cell 5600mAh Main COMMON ID:UM09E70	BT.00607.102
	Battery SIMPLO UM-2009E Li-Ion 3S2P LGC 6 cell 5600mAh Main COMMON ID:UM09E78	BT.00607.103
BOARD		
	Foxconn Wireless LAN Atheros HB93 1x2 BGN (HM)	NI.23600.046
	Lan Intel WLAN 512AG_HMWG Shirley Peak 5100 MM#897072	KI.SPH01.005
	Lan Intel WLAN 512AN_HMWG Shirley Peak 5100 MM#895373	KI.SPH01.003
	Liteon Wireless LAN Atheris HB93 1x2 BGN (HM) WN6602AH	NI.23600.051
	Foxconn Bluetooth FOX BRM 2046 BT2.1	BH.21100.004
	LED BOARD	55.WF807.001
	CRT BOARD	50.SA107.001
	LAN BOARD	55.WF807.003
	TP BOARD	55.WF807.004
CCD		

CATEGORY	PARTNAME	ACER P/N.
	Suyin Camera Rosa 2G, MODULE CN0316-S30C-OV06-1	57.S6507.001
	CAMERA CNF9011(CMOS,0.3M,VGA)	57.S6507.002
CABLE		
	POWER CORD US 3PIN ROHS	27.TAXV7.001
	POWER CORD(EU) 1.8M 3PBLACK FM010008-010	27.TATV7.001
	POWER CORD AU W/LABEL (3 PIN)	27.A50V7.003
	POWER CORD PRC 3P Y536B30001218008	27.TATV7.004
	POWER CORD UK 3PIN	27.A03V7.004
	POWER CORD US-110V (BSMI)	27.A99V7.002
	POWER CORD SWISS 3 PIN	27.A99V7.004
	PWR CORD(ISR)1.8M 3PBLK FZ010008-038	27.TATV7.005
	POWER CORD ITALIAN 3PIN	27.A99V7.005
	POWER CORD(S.A) 1.8M 3BLACK FZ010008-006	27.T48V7.001
	PWR CORD V943B30001218008 DANISH 3P	27.A03V7.006
	PWR CORD V943B30001218008 DANISH 3P	27.A03V7.006
	POWER CORD AF-S (INDIA)	27.A50V7.001
	POWER CORD ARGENTINE 3 PIN BLACK	27.S0207.001
	POWER CORD JAPANESE	27.TAXV7.003
	POWER CORD BRAZIL IMETRO 3 PIN	27.S0607.001
	BLUETOOTH CABLE	50.SA107.001
	CRT CABLE	55.WF807.001
	FFC CABLE - CARD READER/B TO MB	50.SA107.003
	FFC CABLE - LED/B TO MB	50.SA107.001
	LCD CABLE W/MIC FOR CCD	50.SA107.005
	FPC CABLE - HDD TO MB	50.SA107.006

CATEGORY	PARTNAME	ACER P/N.
CASE/COVER/BRACKET ASSEMBLY		
	UPPER CASE ASSY BLACK W/TP, FFC CABLE *2	60.WF807.001
	UPPER CASE ASSY RED W/TP, FFC CABLE *2	60.WFA07.001
	LOWER CASE ASSY W/SPEAKER FOR 3G	60.WF707.001
	LOWER CASE ASSY W/SPEAKER FOR NON 3G	60.WF807.002
	HDD COVER BLACK	42.WF807.002
	RAM COVER BLACK	42.WF807.001
	LCD COVER ASSY PB BLACK W/ANTENNA *2	60.BD807.001
	LCD COVER ASSY PB BLACK W/ANTENNA *3	60.BD807.002
	LCD COVER ASSY PB RED W/ANTENNA *2	60.BD607.001
	LCD COVER ASSY PB RED W/ANTENNA *3	60.BD607.002
	LCD BEZEL ASSY PB BLACK	60.BD807.003
	LCD BRACKET W/HINGE R	60.BD807.003
	LCD BRACKET W/HINGE L	33.WF807.001
	SD DUMMY CARD BLACK	42.WF807.003

CATEGORY	PARTNAME	ACER P/N.
SATA HDD/HARD DISK DRIVE		
	HDD SEAGATE 2.5" 5400rpm 160GB ST9160314AS Wyatt SATA LF F/W:0001SDM1	KH.16001.042
	HDD TOSHIBA 2.5" 5400rpm 160GB MK1655GSX Libra SATA LF F/W: FG011J	KH.16004.006
	HDD HGST 2.5" 5400rpm 160GB HTS545016B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm	KH.16007.026
	HDD SEAGATE 2.5" 5400rpm 250GB ST9250315AS Wyatt SATA LF F/W:0001SDM1	KH.25001.016
	HDD TOSHIBA 2.5" 5400rpm 250GB MK2555GSX Libra SATA LF F/W:FG001J	KH.25004.003
	HDD HGST 2.5" 5400rpm 250GB HTS545025B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm	KH.25007.016
	HDD TOSHIBA 2.5" 5400rpm 320GB MK3255GSX Libra SATA LF F/W:FG011J	KH.32004.002
	HDD SEAGATE 2.5" 5400rpm 500GB ST9500325AS Wyatt SATA LF F/W:0001SDM1	KH.50001.011
	HDD TOSHIBA 2.5" 5400rpm 500GB MK5055GSX Libra SATA LF F/W:FG001J	KH.50004.001
	HDD WD 2.5" 5400rpm 500GB WD5000BEVT-22ZAT0 ML250 SATA LF F/W:01.01A01	KH.50008.013
KEYBOARD		
	Keyboard GATEWAY GP1T SJM11 86KS Black Arabic Texture	KB.I110G.002
	Keyboard GATEWAY GP1T SJM11 87KS Black Belgium Texture	KB.I110G.003
	Keyboard GATEWAY GP1T SJM11 87KS Black Brazilian Portuguese Texture	KB.I110G.004
	Keyboard GATEWAY GP1T SJM11 87KS Black CZ/SK Texture	KB.I110G.005
	Keyboard GATEWAY GP1T SJM11 87KS Black Danish Texture	KB.I110G.007
	Keyboard GATEWAY GP1T SJM11 87KS Black FR/ Arabic Texture	KB.I110G.008
	Keyboard GATEWAY GP1T SJM11 87KS Black French Texture	KB.I110G.009
	Keyboard GATEWAY GP1T SJM11 87KS Black German Texture	KB.I110G.010
	Keyboard GATEWAY GP1T SJM11 86KS Black Greek Texture	KB.I110G.011
	Keyboard GATEWAY GP1T SJM11 87KS Black Hungarian Texture	KB.I110G.012

CATEGORY	PARTNAME	ACER P/N.
	Keyboard GATEWAY GP1T SJM11 87KS Black Italian Texture	KB.I110G.013
	Keyboard GATEWAY GP1T SJM11 91KS Black Japanese Texture	KB.I110G.014
	Keyboard GATEWAY GP1T SJM11 87KS Black Nordic Texture	KB.I110G.015
	Keyboard GATEWAY GP1T SJM11 87KS Black Norwegian Texture	KB.I110G.016
	Keyboard GATEWAY GP1T SJM11 87KS Black Portuguese Texture	KB.I110G.017
	Keyboard GATEWAY GP1T SJM11 86KS Black Russian Texture	KB.I110G.018
	Keyboard GATEWAY GP1T SJM11 87KS Black SLO/CRO Texture	KB.I110G.019
	Keyboard GATEWAY GP1T SJM11 87KS Black Spanish Texture	KB.I110G.020
	Keyboard GATEWAY GP1T SJM11 87KS Black Sweden Texture	KB.I110G.021
	Keyboard GATEWAY GP1T SJM11 87KS Black Swiss/G Texture	KB.I110G.022
	Keyboard GATEWAY GP1T SJM11 86KS Black Thailand Texture	KB.I110G.023
	Keyboard GATEWAY GP1T SJM11 87KS Black Turkish Texture	KB.I110G.024
	Keyboard GATEWAY GP1T SJM11 87KS Black UK Texture	KB.I110G.025
	Keyboard GATEWAY GP1T SJM11 86KS Black Chinese Texture	KB.I110G.006
	Keyboard GATEWAY GP1T SJM11 86KS Black US International Texture	KB.I110G.026
	Keyboard GATEWAY GP1T SJM11 86KS Black US International w/ Hebrew Texture	KB.I110G.027
	Keyboard GATEWAY GP1T SJM11 87KS Black US w/ Canadian French Texture	KB.I110G.028
LCD		
	LED LCD AUO 11.6" WXGA Glare B116XW02 V0 LF 200nit 8ms 500:1	LK.11605.001
	LED LCD CMO 11.6" WXGA Glare N116B6-L02 LF 200nit 10ms 500:1	LK.1160D.001
	LED LCD SAMSUNG 11.6" WXGA Glare LTN116AT01-A01 LF 200nit 8ms	LK.11606.001
	LED LCD LPL 11.6" WXGA Glare LP116WH1-TLA1 LF 200nit 8ms 500:1	LK.11608.001
	LED LCD AUO 11.6" WXGA Glare B116XW02 V0 1A (3G) LF 200nit 8ms 500:1	LK.11605.003
MAINBOARD		

CATEGORY	PARTNAME	ACER P/N.
	MAINBOARD GS45 ICH9M CPU SU3500B W/O RAM FOR 3G	MB.SA506.001
	MAINBOARD GS45 ICH9M CPU SU3500B W/O RAM FOR NON 3G	MB.SA106.001
	MAINBOARD GS45 ICH9M CPU CM723B W/O RAM FOR 3G	MB.SAA06.001
	MAINBOARD GS45 ICH9M CPU CM723B W/O RAM FOR NON 3G	MB.SA706.001
	MAINBOARD GS45 ICH9M CPU SU2700B W/O RAM FOR 3G	MB.PJ306.003
	MAINBOARD GS45 ICH9M CPU SU2700B W/O RAM FOR NON 3G	MB.PJ306.004
	MAINBOARD GS45 ICH9M CPU SU4100B W/O RAM FOR 3G	MB.PJ306.002
MEMORY		
	Memory SAMSUNG SO-DIMM DDRII 667 2GB M470T5663QZ3-CE6 LF	KN.2GB0B.003
	Memory NANYA SO-DIMM DDRII 667 2GB NT2GT64U8HD0BN-3C LF 128*8 0.07um	KN.2GB03.011
	Memory SAMSUNG SO-DIMM DDRII 667 2GB M470T5663EH3-CE6 LF 128*8 0.055um	KN.2GB0B.011
	Memory HYNIX SO-DIMM DDRII 667 2GB HYMP125S64CP8-Y5 LF	KN.2GB0G.004
Heatsink		
	THERMAL MODULE UMA	60.SA107.006
MISCELLANEOUS		
	LOWER CASE SCREW RUBBER	47.WF807.001
	UPPER CASE RUBBER	47.WF807.002
	LOWER CASE RUBBER FOOT - FRONT (LONG)	47.WF807.003
	LOWER CASE RUBBER FOOT - REAR	47.WF807.004
	LCD BEZEL RUBBER	47.WF807.005

Screw List

PARTNAME	ACER P/N
SCREW M2*3.0 I (BNI,NYLOK)IRON	86.WF807.001
SCREW M2*5-I(BZN)(NYLOK)	86.TG607.004
SCREW M2.0*2.5-I (BNI,NYLOK)IRON	86.W0907.005
SCREW M3.0*3.5-I(NI)(NYLOK)STEEL	86.WF807.002

Model Definition and Configuration

Model	RO	Acer Part No	Description
DOTMU-721G16n	EMEA	LU.BCV0X.001	DOTMU-721G16n VHP32DTFR1 UMACKk4 1*1G/160/6L2.2/5R/CB_bgn_0.3D_GEk_FR51 DOT_M/U.FR/010
DOTMU-353G16n	EMEA	LU.BD80Y.001	DOTMU-353G16n VHB32DTNL1 UMACKk8 2G+1G/160/6L2.8/5R/CB_n2_0.3D_BAG_GEk_NL31 DOT_M/U.NL/300
DOTMU-352G25n	EMEA	LU.BD80X.004	DOTMU-352G25n VHP32DTFR1 UMACKk8 2*1G/250/6L2.8/5R/CB_n2_0.3D_GEk_FR51 DOT_M/U.FR/020
DOTMU-354G32n	EMEA	LU.BD80X.003	DOTMU-354G32n VHP32DTES1 UMACKk8 2*2G/320/BT/6L2.8/5R/CB_n2_0.3D_BAG_GEk_ES31 DOT_M/U.SP/001
DOTMU-354G32n	EMEA	LU.BD80X.002	DOTMU-354G32n VHP32DTND1 UMACKk8 2*2G/320/6L2.8/5R/CB_n2_0.3D_GEk_ENU1 DOT_M/U.NC/860
DOTMU-354G32n	EMEA	LU.BD80X.001	DOTMU-354G32n VHP32DTFR1 UMACKk8 2*2G/320/6L2.8/5R/CB_n2_0.3D_GEk_FR51 DOT_M/U.FR/021

Model	CPU	LCD	VGA Chip	Memory 1	HDD 1(GB)
DOTMU-721G16n	CM723B	NLED11.6WXGAG	UMA	SO1GBII6	N160GB5.4KS
DOTMU-353G16n	C2SSU3500B	NLED11.6WXGAG	UMA	SO2GBII6	N160GB5.4KS
DOTMU-352G25n	C2SSU3500B	NLED11.6WXGAG	UMA	SO1GBII6	N250GB5.4KS
DOTMU-354G32n	C2SSU3500B	NLED11.6WXGAG	UMA	SO2GBII6	N320GB5.4KS
DOTMU-354G32n	C2SSU3500B	NLED11.6WXGAG	UMA	SO2GBII6	N320GB5.4KS
DOTMU-354G32n	C2SSU3500B	NLED11.6WXGAG	UMA	SO2GBII6	N320GB5.4KS

Model	Extra SW1	Card Reader	Wireless LAN	Wireless LAN1	Blue tooth	Battery
DOTMU-721G16n	NIS	5 in 1-Build in	3rd WiFi 1x2 BGN	3rd WiFi 1x2 BGN	N	6CELL2.2
DOTMU-353G16n	NIS	5 in 1-Build in	SP1x2HMMW	SP1x2HMMW	N	6CELL2.8
DOTMU-352G25n	NIS	5 in 1-Build in	SP1x2HMMW	SP1x2HMMW	N	6CELL2.8
DOTMU-354G32n	NIS	5 in 1-Build in	SP1x2HMMW	SP1x2HMMW	BT 2.1	6CELL2.8

Model	Extra SW1	Card Reader	Wireless LAN	Wireless LAN1	Blue tooth	Battery
DOTMU-354G32n	NIS	5 in 1-Build in	SP1x2HMMW	SP1x2HMMW	N	6CELL2.8
DOTMU-354G32n	NIS	5 in 1-Build in	SP1x2HMMW	SP1x2HMMW	N	6CELL2.8

Test Compatible Components

This computer's compatibility is tested and verified by Acer's internal testing department. All of its system functions are tested under Windows® XP Home, Windows® XP Pro environment.

Refer to the following lists for components, adapter cards, and peripherals which have passed these tests. Regarding configuration, combination and test procedures, please refer to the Compatibility Test Report released by the Acer Mobile System Testing Department.

BRAND	Type	Description
3G		
Qualcomm	Gobi2000	Qualcomm Gobi2000
A cover		
	Black IMR	Black IMR
	Red IMR	Red IMR
Accessory		
PackardBell	PackardBell 11inch Netbook Bag black	PackardBell Accessory PackardBell 11" Netbook Bag Black
Adapter		
DELTA	30W	Adapter DELTA 30W 19V 1.7x5.5x11 Black ADP-30JH BA LF
HIPRO	30W	Adapter HIPRO 30W 19V 1.7x5.5x11 Black HP-A0301R3 B1LF LF
LITE-ON	30W	Adapter LITE-ON 30W 19V 1.7x5.5x11 Black PA-1300-04AC LF
Audio Codec		
Realtek	ALC269X	Realtek Audio Codec ALC269X
B cover		
	Mirror w/Camera	Mirror w/Camera
Battery		
PANASONIC	6CELL2.2	Battery PANASONIC UM-2009E Li-Ion 3S2P PANASONIC 6 cell 4400mAh Main COMMON ID:UM09E51
SANYO	6CELL2.2	Battery SANYO UM-2009E Li-Ion 3S2P SANYO 6 cell 4400mAh Main COMMON ID: UM09E31
SANYO	6CELL2.8	Battery SANYO UM-2009E Li-Ion 3S2P SANYO 6 cell 5600mAh Main COMMON ID:UM09E36
SIMPLO	6CELL2.2	Battery SIMPLO UM-2009E Li-Ion 3S2P PANASONIC 6 cell 4400mAh Main COMMON ID:UM09E71
SIMPLO	6CELL2.2	Battery SIMPLO UM-2009E Li-Ion 3S2P PANASONIC 6 cell 4400mAh Main COMMON ID:UM09E71
SIMPLO	6CELL2.8	Battery SIMPLO UM-2009E Li-Ion 3S2P SAMSUNG 6 cell 5600mAh Main COMMON ID:UM09E70
SIMPLO	6CELL2.8	Battery SIMPLO UM-2009E Li-Ion 3S2P SAMSUNG 6 cell 5600mAh Main COMMON ID:UM09E70
Bluetooth		

BRAND	Type	Description
Foxconn	BT 2.1	Foxconn Bluetooth BRM 2046 BT2.1 (T60H928.33) f/w:861
Camera		
Chicony	0.3M LDV	Chicony Camera Lilac_2G
Suyin	0.3M LDV	Suyin Camera Rose_2G
Card Reader		
	5 in 1-Build in	5 in 1-Build in MS, MS Pro, SD, SC, XD
INTEL	C2SSU3500B	CPU Intel Core2Solo SU3500 BGA 1.4G 3M 800 5.5W ULV
INTEL	CM723B	CPU Intel Celeron 723 BGA 1.2G 1M 800 10W R-0 ULV
HDD		
HGST	N160GB5.4KS	HDD HGST 2.5" 5400rpm 160GB Falcon B HTS543216L9SA00 SATA LF F/W:C40C
HGST	N160GB5.4KS	HDD HGST 2.5" 5400rpm 160GB HTS545016B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
HGST	N250GB5.4KS	HDD HGST 2.5" 5400rpm 250GB HTS545025B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
HGST	N250GB5.4KS	HDD HGST 2.5" 5400rpm 250GB HTS545025B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
HGST	N320GB5.4KS	HDD HGST 2.5" 5400rpm 320GB HTS545032B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
SEAGATE	N160GB5.4KS	HDD SEAGATE 2.5" 5400rpm 160GB ST9160314AS Wyatt SATA LF F/W:0001SDM1
SEAGATE	N250GB5.4KS	HDD SEAGATE 2.5" 5400rpm 250GB ST9250315AS Wyatt SATA LF F/W:0001SDM1
SEAGATE	N320GB5.4KS	HDD SEAGATE 2.5" 5400rpm 320GB ST9320325AS Wyatt SATA LF F/W:0001SDM1
TOSHIBA	N160GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 160GB MK1655GSX Libra SATA LF F/W: FG011J
TOSHIBA	N250GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 250GB MK2555GSX Libra SATA LF F/W:FG001J
TOSHIBA	N320GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 320GB MK3255GSX Libra SATA LF F/W:FG011J
WD	N160GB5.4KS	HDD WD 2.5" 5400rpm 160GB WD1600BEVT-22ZCT0 ML160 SATA LF F/W:11.01A11
WD	N250GB5.4KS	HDD WD 2.5" 5400rpm 250GB WD2500BEVT-22ZCT0 ML160 SATA LF F/W:11.01A11
WD	N320GB5.4KS	HDD WD 2.5" 5400rpm 320GB WD3200BEVT-22ZCT0 ML160 SATA LF F/W:11.01A11
Keyboard		
ACER	NT1T	Keyboard ACER NT-1T JV11 Internal 11 Standard Black NONE Texture
LAN		
Atheros	AR8131L	Atheros AR8131L

BRAND	Type	Description
LCD		
AUO	NLED11.6WXGAG	LED LCD AUO 11.6" WXGA Glare B116XW02 V0 LF 200nit 8ms 500:1
AUO	NLED11.6WXGAG	LED LCD AUO 11.6" WXGA Glare B116XW02 V0 2A LF 200nit 8ms 500:1
AUO	NLED11.6WXGAG	LED LCD AUO 11.6" WXGA Glare B116XW02 V0 1A (3G) LF 200nit 8ms 500:1
CMO	NLED11.6WXGAG	LED LCD CMO 11.6" WXGA Glare N116B6-L02 C2 LF 200nit 10ms 500:1
LPL	NLED11.6WXGAG	LED LCD LPL 11.6" WXGA Glare LP116WH1-TLA1 LF 200nit 8ms 500:1
SAMSUNG	NLED11.6WXGAG	LED LCD SAMSUNG 11.6" WXGA Glare LTN116AT01-A01 LF 200nit 8ms
MEM		
HYNIX	SO1GBII6	Memory HYNIX SO-DIMM DDRII 667 1GB HYMP112S64CP6-Y5 LF
HYNIX	SO2GBII6	Memory HYNIX SO-DIMM DDRII 667 2GB HYMP125S64CP8-Y5 LF
NANYA	SO1GBII6	Memory NANYA SO-DIMM DDRII 667 1GB NT1GT64UH8D0FN-3C LF 64*16 0.07um
NANYA	SO2GBII6	Memory NANYA SO-DIMM DDRII 667 2GB NT2GT64U8HD0BN-3C LF 128*8 0.07um
SAMSUNG	SO1GBII6	Memory SAMSUNG SO-DIMM DDRII 667 1GB M470T2864QZ3-CE6 LF
SAMSUNG	SO1GBII6	Memory SAMSUNG SO-DIMM DDRII 667 1GB M470T2864QZ3-CE6 LF
SAMSUNG	SO2GBII6	Memory SAMSUNG SO-DIMM DDRII 667 2GB M470T5663QZ3-CE6 LF
SAMSUNG	SO2GBII6	Memory SAMSUNG SO-DIMM DDRII 667 2GB M470T5663QZ3-CE6 LF
NB Chipset		
INTEL	GS45	NB Chipset Intel CS GS45NB
SB Chipset		
INTEL	ICH9M-SFFE	SB Chipset Intel CS AM82801IUX MM#898134
Software		
	NIS	Antivirus application NIS

Online Support Information

This section describes online technical support services available to help you repair your Acer Systems.

If you are a distributor, dealer, ASP or TPM, please refer your technical queries to your local Acer branch office. Acer Branch Offices and Regional Business Units may access our website. However some information sources will require a user i.d. and password. These can be obtained directly from Acer CSD Taiwan.

Acer's Website offers you convenient and valuable support resources whenever you need them.

In the Technical Information section you can download information on all of Acer's Notebook, Desktop and Server models including:

- Service guides for all models
- User's manuals
- Training materials
- Bios updates
- Software utilities
- Spare parts lists
- TABs (Technical Announcement Bulletin)

For these purposes, we have included an Acrobat File to facilitate the problem-free downloading of our technical material.

Also contained on this website are:

- Detailed information on Acer's International Traveler's Warranty (ITW)
- Returned material authorization procedures
- An overview of all the support services we offer, accompanied by a list of telephone, fax and email contacts for all your technical queries.

We are always looking for ways to optimize and improve our services, so if you have any suggestions or comments, please do not hesitate to communicate these to us.

A

- Antennas
 - Removing 82, 84

B

- Battery Pack
 - Removing 45
- BIOS
 - ROM type 19
 - vendor 19
 - Version 19
- BIOS Utility 25–33
 - Advanced 28
 - Boot 31
 - Exit 32
 - Navigating 25
 - Power 31
 - Save and Exit 32
 - Security 28
 - System Security 32
- brightness
 - hotkeys 13
- Button Board
 - Removing 59

C

- Camera Board
 - Removing 77, 90
- caps lock
 - on indicator 9
- Common Problems 122
- CRT Cable
 - Removing 69

D

- DIMM Module
 - Removing 49
- Display 4
- display
 - hotkeys 13

E

- Euro Key 14
- External Module Disassembly

Flowchart 44

F

- Features 1
- FLASH Utility 33
- Flash Utility 33
- FRU (Field Replaceable Unit) List 141

H

- Hard Disk Drive Module
 - Removing 47
- Hibernation mode
 - hotkey 13
- Hot Keys 11

I

- Indicators 9
- Intermittent Problems 132
- Internal Microphone Failure 129
- Internal Speaker Failure 128

J

- Jumper and Connector Locations 137

K

- Keyboard
 - Removing 55
- Keyboard Failure 126

L

- LCD Bezel
 - Removing 76, 91
- LCD Brackets
 - Removing 81
- LCD Cable
 - Removing 81
- LCD Failure 125
- LCD Module
 - Removing 104
- LCD Module Disassembly
 - Flowchart 75
- LCD Panel

Removing 78, 88

M

Main Unit Disassembly

Flowchart 53

Mainboard

Removing 69

media access

on indicator 9

Memory Check 122

Microphone

Removing 78, 88

Model Definition 151

N

No Display Issue 123

num lock

on indicator 9

O

ODD Failure 131

Online Support Information 157

P

Panel 5

PC Card 9

Power On Failure 122

S

Speaker Module

Removing 66

speakers

hotkey 13

System

Block Diagram 4

T

Test Compatible Components 153

Thermal Module

Removing 72

Touch Pad Failure 127

Troubleshooting

Built-in KB Failure 126

Internal Microphone 129

Internal Speakers 128

LCD Failure 125

No Display 123

ODD 131

Other Failures 131

Power On 122

Touch Pad 127

USB 131

U

Undetermined Problems 132

Upper Cover

Removing 57

USB Failure (Rightside) 131

utility

BIOS 25–33

V

volume

hotkeys 13

W

Windows 2000 Environment Test 153

WLAN Board

Removing 51

